

LISTA DE APLICACIONES - BUYERS GUIDE

141046-700




8 424073 053732


Qty: 639

Weight: 1.645

O.E.M.	MAKE
16 114 581 80	CITROËN
16 172 492 80	CITROËN
4251.09	PEUGEOT
4251.10	PEUGEOT
4254.53	CITROËN
7 175 299 2	FIAT
7 177 0974	FIAT
7 736 223 7	FORD
86 60 004 675	RENAULT
86 71 016 617	RENAULT
9 946 016	LANCIA
E172039	CITROËN



141046-700



1-690022

141046-700



E1 90R-01217/039

Lucas - Girling

130x58.8x19

WVA
21801
21802
21963

MAKE
CITROËN
FIAT
LANCIA
MERCEDES-BENZ
PEUGEOT



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

CITROËN

EVASION / SYNERGIE (U6_, AF_) 03.94-10.02					Box Body/MPV (Large MPV-M1 Segment)				
2.0 (AFRFVB)		Gasolina	FWD	1998	97	132	05.98-04.00		■
TD (U6UJ)	-12/00	Diesel	FWD	1905	66	90	11.94-07.02		■
DT (U6UC)		Diesel	FWD	1905	68	92	10.95-12.98		■
HDi (AFRHWB)		Diesel	FWD	1997	80	109	09.99-10.02		■
HDi (AFRHZA)		Diesel	FWD	1997	80	109	09.99-10.02		■
DT (U6UW)		Diesel	FWD	2088	80	109	11.96-08.00		■
EVASION / SYNERGIE (22, U6) 03.94-07.02					MPV (Large MPV-M1 Segment)				
1.9	01/95-	Gasolina	FWD	1895	68	92	03.94-		■
1.9 ABS	01/95-	Gasolina	FWD	1895	68	92	03.94-		■
2.0	01/95-	Gasolina	FWD	1995	90	122	03.94-		■
2.0	01/95-	Gasolina	FWD	1995	98	133	03.94-		■
2.0 SX	01/00-	Gasolina	FWD	1995	99	135	03.94-		■
2.0 16V (RFN (EW10J4))		Gasolina	FWD	1997	100	136	05.00-07.02		■
2.0 (RFU (XU10J2/C))	-12/00	Gasolina	FWD	1998	89	121	06.94-07.02		■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	05.98-04.00		■
2.0 Turbo C.T. (RGX (XU10J2TE))	-12/00	Gasolina	FWD	1998	108	147	06.94-07.02		■
1.9 TD (D8B (XUD9TF))	-12/00	Diesel	FWD	1905	66	90	11.94-07.02		■
1.9 TD (DHX (XUD9TF/BTF))	-12/00	Diesel	FWD	1905	66	90	11.94-07.02		■
1.9 TD (D8B (XUD9TF))		Diesel	FWD	1905	68	92	10.95-12.98		■
2.0 HDi	01/99-	Diesel	RWD	1995	81	110	03.94-		■
2.0 HDi (RHZ (DW10ATED))		Diesel	FWD	1997	80	109	08.99-07.02		■
2.0 HDi 16V (RHW (DW10ATED4))		Diesel	FWD	1997	80	109	09.99-07.02		■

LISTA DE APLICACIONES - BUYERS GUIDE

2.0 HDi		Diesel	FWD	1997	81	110	08.99-07.02	■
2.1 TD (P8C (XUD11BTE))		Diesel	FWD	2088	80	109	05.96-07.02	■
JUMPY / DISPATCH (U6U_) 06.94-12.06					Bus (Minibus-M2-Segment)			
2.0 (RFN (EW10J4))		Gasolina	FWD	1997	100	136	04.00-12.06	■
2.0 i 16V (RFN (EW10J4))		Gasolina	FWD	1997	102	138	03.00-10.06	■
1.9 TD (DHX (XUD9TF/BTF))		Diesel	FWD	1905	66	90	10.95-08.00	■
2.0 HDi 95 (RHX (DW10BTED))		Diesel	FWD	1997	69	94	10.99-10.06	■
2.0 HDi 110 (RHZ (DW10ATED))		Diesel	FWD	1997	80	109	03.00-10.06	■
JUMPY / DISPATCH (BU_, BV_, BW_, BX_) 10.99-10.06					Platform/Chassis (LCVs-N1 Segment)			
1.9 TD (D8B (XUD9TE))		Diesel	FWD	1905	68	92	10.99-10.06	■
2.0 HDi 95 (RHX (DW10BTED))		Diesel	FWD	1997	69	94	10.99-10.06	■
JUMPY / DISPATCH (BS_, BT_, BY_, BZ_) 06.94-10.06					Van (LCVs-N1 Segment)			
2.0 i 16V (RFN (EW10J4))		Gasolina	FWD	1997	102	138	03.00-10.06	■
1.9 DT		Diesel	FWD	1905	65	88	10.95-08.00	■
1.9 TD (DHX (XUD9TF/BTF))		Diesel	FWD	1905	66	90	10.95-08.00	■
1.9 TD (D8B (XUD9TE))		Diesel	FWD	1905	68	92	10.95-08.00	■
2.0 HDi 95 (RHX (DW10BTED))		Diesel	FWD	1997	69	94	10.99-10.06	■
2.0 HDi 110 (RHW (DW10ATED4))	-08/03, -Org. 09792	Diesel	FWD	1997	80	109	01.02-10.06	■
2.0 HDi 110 (RHZ (DW10ATED))		Diesel	FWD	1997	80	109	10.01-10.06	■
2.0 HDi 110 (RHZ (DW10BTED))		Diesel	FWD	1997	80	109	10.01-10.06	■
2.0 HDi 110 (RHZ (DW10BTED+))		Diesel	FWD	1997	80	109	10.01-10.06	■
2.0 HDi 110 (RHZ (DW10CTED))		Diesel	FWD	1997	80	109	10.01-10.06	■
2.0 HDi 110 (RHZ (DW10CTED+))		Diesel	FWD	1997	80	109	10.01-10.06	■
2.2 HDi		Diesel	RWD	2179	66	90	12.03-10.06	■
FIAT								
SCUDO (220_) 02.96-12.06					Bus (Minibus-M2-Segment)			
2.0 16V (RFN (EW10J4))		Gasolina	FWD	1997	100	136	06.00-12.06	■
2.0 JTD (RHX)		Diesel	FWD	1997	69	94	01.04-12.06	■
2.0 JTD (RHZ)		Diesel	FWD	1997	80	109	12.99-12.06	■
2.0 JTD 16V (RHW (DW10ATED4))		Diesel	FWD	1997	80	109	05.99-12.06	■
SCUDO (220_) 09.96-12.06					Platform/Chassis (LCVs-N1 Segment)			
1.9 TD (D8B)		Diesel	FWD	1905	68	92	09.96-12.06	■
1.9 TD (DHX (XUD9TF/L))		Diesel	FWD	1905	68	92	09.96-12.06	■
2.0 JTD (RHX)		Diesel	FWD	1997	69	94	10.99-12.06	■
2.0 JTD (RHZ)		Diesel	FWD	1997	80	109	12.02-12.06	■
2.0 JTD 16V (RHK (DW10UTED4))		Diesel	FWD	1997	80	109	05.99-12.06	■
2.0 JTD 16V (RHW (DW10ATED4))		Diesel	FWD	1997	80	109	05.99-12.06	■
SCUDO (220_) 02.96-12.06					Van (LCVs-N1 Segment)			
2.0 JTD (RHX)		Diesel	FWD	1997	69	94	10.99-12.06	■
2.0 JTD (RHZ)		Diesel	FWD	1997	80	109	12.02-12.06	■
2.0 JTD 16V (RHK (DW10UTED4))		Diesel	FWD	1997	80	109	05.99-12.06	■
2.0 JTD 16V (RHM (DW10ATED4))		Diesel	FWD	1997	80	109	05.99-12.06	■
2.0 JTD 16V (RHW (DW10ATED4))		Diesel	FWD	1997	80	109	05.99-12.06	■
ULYSSE (220_) 06.94-08.02					MPV (Large MPV-M1 Segment)			
2.0 16V (220AQ5) (RFN (EW10J4))		Gasolina	FWD	1997	100	136	09.00-08.02	■
2.0 (220.AC5) (RFU (XU10J2C))		Gasolina	FWD	1998	89	121	06.94-08.02	■
2.0 16V (RFV)		Gasolina	FWD	1998	97	132	05.98-09.00	■
2.0 Turbo (220.AD5) (RGX (XU10J2CTE))		Gasolina	FWD	1998	108	147	06.94-08.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.9 TD (220AH5) (DHX (XUD9TF/L))		Diesel	FWD	1905	66	90	02.95-08.02	■
1.9 TD (DHX (XUD9TF/L))		Diesel	FWD	1905	68	92	05.97-12.99	■
2.0 JTD (RHZ)		Diesel	FWD	1997	80	109	10.99-08.02	■
2.0 JTD 16V (RHW (DW10ATED4))		Diesel	FWD	1997	80	109	05.99-08.02	■
2.1 TD (P8C)		Diesel	FWD	2088	80	109	03.96-10.99	■
LANCIA								
ZETA (22_) 05.95-10.03					MPV (Large MPV-M1 Segment)			
2.0 16V (220AQ5, 220AQ4) (RFN)		Gasolina	FWD	1997	100	136	07.00-09.02	■
2.0 16V (220AL5) (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	05.98-07.00	■
2.0 Turbo (220AD5, 220CD5) (RGX (XU10J2TE))		Gasolina	FWD	1998	108	147	05.95-09.02	■
2.0 JTD (220.AR5, 220.AN5) (RHZ (DW10ATED))		Diesel	FWD	1997	80	109	09.99-09.02	■
2.0 JTD 16V (220AN5)		Diesel	FWD	1997	80	109	09.99-09.02	■
2.0 JTD 16V (220.AR5OOL) (RHW (DW10ATED4))		Diesel	FWD	1997	81	110	04.01-10.03	■
2.1 TD (220AJ5) (P 8 C)		Diesel	FWD	2088	80	109	05.96-09.99	■
MERCEDES-BENZ								
R 07.11-					Tractor Axle			
R440-10A/C22.5							07.11-	■
PEUGEOT								
806 (AF_) 06.94-02.03					Box Body/MPV (Large MPV-M1 Segment)			
2.0 (AFRFNC)		Gasolina	FWD	1997	100	136	05.00-02.03	■
2.0 (AFRFVC)		Gasolina	FWD	1998	97	132	05.98-09.00	■
2.0 (AFRGXC)		Gasolina	FWD	1998	108	147	02.97-05.00	■
TD (AFDHXC)		Diesel	FWD	1905	66	90	07.95-08.02	■
HDi (AFRHZC)		Diesel	FWD	1997	80	109	06.99-02.03	■
DT (AFP8CB)		Diesel	FWD	2088	80	109	02.97-05.00	■
806 (221) 06.94-08.02					MPV (Large MPV-M1 Segment)			
2.0 16V (RFN (EW10J4))		Gasolina	FWD	1997	100	136	09.00-08.02	■
2.0 (RFU (XU10J2))		Gasolina	FWD	1998	89	121	06.94-08.02	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	05.98-09.00	■
2.0 Turbo (RGX (XU10J2TE))		Gasolina	FWD	1998	108	147	06.94-08.02	■
1.9 TD (DHX (XUD9TE))		Diesel	FWD	1905	66	90	07.95-08.02	■
1.9 TD (D8B (XUD9TE))		Diesel	FWD	1905	68	92	05.97-08.02	■
2.0 HDi (RHZ (DW10ATED))		Diesel	FWD	1997	80	109	08.99-08.02	■
2.0 HDi 16V (RHW (DW10ATED4))		Diesel	FWD	1997	80	109	08.99-08.02	■
2.1 TD 12V (P8C (XUD11BTE))		Diesel	FWD	2088	80	109	06.96-08.99	■
EXPERT (224_) 10.95-12.06					Bus (Minibus-M2-Segment)			
2.0 (RFN (EW10J4))		Gasolina	FWD	1997	100	136	07.00-12.06	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	12.03-12.06	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	12.03-12.06	■
1.9 D (D9B (XUD9AU))		Diesel	FWD	1905	51	70	02.96-12.98	■
1.9 TD (DHX (XUD9TE))		Diesel	FWD	1905	66	90	02.96-09.00	■
1.9 TD (D8B (XUD9TE))		Diesel	FWD	1905	68	92	02.96-05.98	■
1.9 D		Diesel	RWD	1905	69	94	10.95-05.98	■
2.0 HDi (RHX (DW10BTED))		Diesel	FWD	1997	69	94	10.00-10.06	■
2.0 HDi (RHZ (DW10ATED))		Diesel	FWD	1997	80	109	07.00-12.06	■
2.0 HDi (RHZ (DW10BTED))		Diesel	FWD	1997	80	109	07.00-12.06	■
2.0 HDi (RHZ (DW10BTED+))		Diesel	FWD	1997	80	109	07.00-12.06	■
2.0 HDi (RHZ (DW10CTED))		Diesel	FWD	1997	80	109	07.00-12.06	■

LISTA DE APLICACIONES - BUYERS GUIDE

2.0 HDI 16V (RHW (DW10ATED4))	Diesel	FWD	1997	80	109	07.00-12.06	■
EXPERT (223) 12.95-12.06				Platform/Chassis (LCVs-N1 Segment)			
1.9 D (WJY (DW8B))	Diesel	FWD	1868	51	69	06.98-09.01	■
1.9 D (WJZ (DW8))	Diesel	FWD	1868	51	69	06.98-09.01	■
1.9 D (D9B (XUD9AU))	Diesel	FWD	1905	51	70	02.96-12.98	■
1.9 TD (DHX (XUD9TE))	Diesel	FWD	1905	66	90	02.96-09.00	■
1.9 TD (D8B (XUD9TE))	Diesel	FWD	1905	68	92	02.96-05.98	■
2.0 HDi (RHX (DW10BTED))	Diesel	FWD	1997	69	94	10.00-10.06	■
2.0 HDi (RHW (DW10ATED4))	Diesel	FWD	1997	80	109	10.00-10.06	■
2.0 HDi	Diesel	FWD	1997	80	109	10.00-10.06	■
EXPERT (222) 07.95-03.08				Van (LCVs-N1 Segment)			
2.0 (RFN (EW10J4))	Gasolina	FWD	1997	100	136	09.02-12.06	■
1.9 D 70 (WJY (DW8B))	Diesel	FWD	1868	51	69	12.98-12.06	■
1.9 D 70 (WJZ (DW8))	Diesel	FWD	1868	51	69	12.98-12.06	■
1.9 D (D9B (XUD9AU))	Diesel	FWD	1905	51	70	02.96-12.98	■
1.9 TD (DHX (XUD9TE))	Diesel	FWD	1905	66	90	02.96-09.00	■
1.9 TD (D8B (XUD9TE))	Diesel	FWD	1905	68	92	02.96-05.98	■
2.0 HDi (RHX (DW10BTED))	Diesel	FWD	1997	69	94	07.00-12.06	■
2.0 HDi (RHZ (DW10ATED))	Diesel	FWD	1997	80	109	07.00-12.06	■
2.0 HDi (RHZ (DW10BTED))	Diesel	FWD	1997	80	109	07.00-12.06	■
2.0 HDi (RHZ (DW10BTED+))	Diesel	FWD	1997	80	109	07.00-12.06	■
2.0 HDi (RHZ (DW10CTED))	Diesel	FWD	1997	80	109	07.00-12.06	■
2.0 HDi (RHW (DW10ATED4))	Diesel	FWD	1997	80	109	07.00-12.06	■