

# LISTA DE APLICACIONES - BUYERS GUIDE

## 21 9494 00






8 424073 077530

Qty: 850

Weight: 7.600

| O.E.M.        | MAKE          |
|---------------|---------------|
| 617 423 17 30 | MERCEDES-BENZ |



## 21 9494 00



163x17x178- Ø410

| WVA           |
|---------------|
| 19486         |
| 19494         |
| MAKE          |
| MAN           |
| MERCEDES-BENZ |



| Trac. | CC | Kw | CV |  |              |
|-------|----|----|----|--|--------------|
|       |    |    |    |  |              |
|       |    |    |    |  | Front / Rear |

### MAN

#### F90 06.86-12.97

|                 |        |        |  |  |     |     |        |   |
|-----------------|--------|--------|--|--|-----|-----|--------|---|
| 27.272 DF/DFA   | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.272 DF/DFA   | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.272 DFK/DFAK | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.272 DFK/DFAK | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.272 DFS/DFAS | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.272 DFS/DFAS | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.422 DFK/DFAK | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.422 DFK/DFAK | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.422 DFS/DFAS | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.422 DFS/DFAS | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.472 DF/DFA   | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.472 DF/DFA   | 01/93- | Diesel |  |  | 198 | 270 | 06.86- | ■ |
| 27.322 DF/DFA   | 01/93- | Diesel |  |  | 235 | 320 | 06.86- | ■ |
| 27.322 DF/DFA   | 01/93- | Diesel |  |  | 235 | 320 | 06.86- | ■ |
| 27.322 DFK/DFAK | 01/93- | Diesel |  |  | 235 | 320 | 06.86- | ■ |
| 27.322 DFK/DFAK | 01/93- | Diesel |  |  | 235 | 320 | 06.86- | ■ |
| 27.322 DFS/DFAS | 01/93- | Diesel |  |  | 235 | 320 | 06.86- | ■ |
| 27.322 DFS/DFAS | 01/93- | Diesel |  |  | 235 | 320 | 06.86- | ■ |
| 27.372 DF/DFA   | 01/93- | Diesel |  |  | 272 | 370 | 06.86- | ■ |
| 27.372 DF/DFA   | 01/93- | Diesel |  |  | 272 | 370 | 06.86- | ■ |
| 27.372 DFK/DFAK | 01/93- | Diesel |  |  | 272 | 370 | 06.86- | ■ |
| 27.372 DFK/DFAK | 01/93- | Diesel |  |  | 272 | 370 | 06.86- | ■ |
| 27.372 DFS/DFAS | 01/93- | Diesel |  |  | 272 | 370 | 06.86- | ■ |

# LISTA DE APLICACIONES - BUYERS GUIDE

|                 |        |        |  |       |     |     |        |   |
|-----------------|--------|--------|--|-------|-----|-----|--------|---|
| 27.372 DFS/DFAS | 01/93- | Diesel |  |       | 272 | 370 | 06.86- | ■ |
| 27.502 DFA      | 01/93- | Diesel |  |       | 368 | 500 | 06.86- | ■ |
| 27.502 DFA      | 01/93- | Diesel |  |       | 368 | 500 | 06.86- | ■ |
| 27.502 DFAS     | 01/93- | Diesel |  |       | 368 | 500 | 06.86- | ■ |
| 27.502 DFAS     | 01/93- | Diesel |  |       | 368 | 500 | 06.86- | ■ |
| 41.262VFAK      | 01/93- | Diesel |  | 10000 | 191 | 260 | 06.86- | ■ |
| 41.262VFAK      | 01/93- | Diesel |  | 10000 | 191 | 260 | 06.86- | ■ |
| 19.272FA        | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 19.272FA        | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 19.272FAK       | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 19.272FAK       | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 19.272FAS       | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 19.272FAS       | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 26.272DF        | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 26.272DF        | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 26.272DFK       | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 26.272DFK       | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 26.272DFS/DFLS  | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 26.272DFS/DFLS  | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 33.272DFA       | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 33.272DFA       | 01/93- | Diesel |  | 10000 | 198 | 269 | 06.86- | ■ |
| 19.322FA        | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 19.322FA        | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 19.322FAK       | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 19.322FAK       | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 19.322FAS       | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 19.322FAS       | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 26.322DF        | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 26.322DF        | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 26.322DFK       | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 26.322DFK       | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 26.322DFS/DFLS  | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 26.322DFS/DFLS  | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 26.322UNL/UNLL  | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 26.322UNL/UNLL  | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 33.322DFA       | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 33.322DFA       | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 35.322VF        | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 35.322VF        | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 35.322VFAK      | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 35.322VFAK      | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 35.322VFK       | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 35.322VFK       | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 35.322VFKK      | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 35.322VFKK      | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 41.322VF        | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 41.322VF        | 01/93- | Diesel |  | 10000 | 235 | 320 | 06.86- | ■ |
| 19.342FA        | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 19.342FA        | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 19.342FAK       | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 19.342FAK       | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |

# LISTA DE APLICACIONES - BUYERS GUIDE

|                |        |        |  |       |     |     |        |   |
|----------------|--------|--------|--|-------|-----|-----|--------|---|
| 19.342FAS      | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 19.342FAS      | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 26.342DF/DFL   | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 26.342DF/DFL   | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 26.342DFK/DFLK | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 26.342DFK/DFLK | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 26.342DFS      | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 26.342DFS      | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 33.342DFA      | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 33.342DFA      | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 35.342VF       | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 35.342VF       | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 35.342VFK      | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 35.342VFK      | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 41.342VF       | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 41.342VF       | 01/94- | Diesel |  | 10000 | 250 | 340 | 06.86- | ■ |
| 35.292VF       | 01/93- | Diesel |  | 11995 | 213 | 290 | 06.86- | ■ |
| 35.292VF       | 01/93- | Diesel |  | 11995 | 213 | 290 | 06.86- | ■ |
| 35.292VFK      | 01/93- | Diesel |  | 11995 | 213 | 290 | 06.86- | ■ |
| 35.292VFK      | 01/93- | Diesel |  | 11995 | 213 | 290 | 06.86- | ■ |
| 41.292VFAK     | 01/93- | Diesel |  | 11995 | 213 | 290 | 06.86- | ■ |
| 41.292VFAK     | 01/93- | Diesel |  | 11995 | 213 | 290 | 06.86- | ■ |
| 41.322VFAK     | 01/93- | Diesel |  | 11995 | 235 | 320 | 06.86- | ■ |
| 41.322VFAK     | 01/93- | Diesel |  | 11995 | 235 | 320 | 06.86- | ■ |
| 35.332VF       | 01/93- | Diesel |  | 11995 | 243 | 330 | 06.86- | ■ |
| 35.332VF       | 01/93- | Diesel |  | 11995 | 243 | 330 | 06.86- | ■ |
| 35.332VFK      | 01/93- | Diesel |  | 11995 | 243 | 330 | 06.86- | ■ |
| 35.332VFK      | 01/93- | Diesel |  | 11995 | 243 | 330 | 06.86- | ■ |
| 41.332VFAK     | 01/93- | Diesel |  | 11995 | 243 | 330 | 06.86- | ■ |
| 41.332VFAK     | 01/93- | Diesel |  | 11995 | 243 | 330 | 06.86- | ■ |
| 35.372VF       | 01/93- | Diesel |  | 11995 | 249 | 339 | 06.86- | ■ |
| 35.372VF       | 01/93- | Diesel |  | 11995 | 249 | 339 | 06.86- | ■ |
| 35.372VFK      | 01/93- | Diesel |  | 11995 | 249 | 339 | 06.86- | ■ |
| 35.372VFK      | 01/93- | Diesel |  | 11995 | 249 | 339 | 06.86- | ■ |
| 41.362VFAK     | 01/93- | Diesel |  | 11995 | 265 | 360 | 06.86- | ■ |
| 41.362VFAK     | 01/93- | Diesel |  | 11995 | 265 | 360 | 06.86- | ■ |
| 19.372FA       | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 19.372FA       | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 19.372FAK      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 19.372FAK      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 19.372FAS      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 19.372FAS      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 26.372DF/DFL   | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 26.372DF/DFL   | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 26.372DFAK     | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 26.372DFAK     | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 26.372DFK      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 26.372DFK      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 26.372DFS      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 26.372DFS      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 33.372DFA      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |

# LISTA DE APLICACIONES - BUYERS GUIDE

|                |        |        |  |       |     |     |        |   |
|----------------|--------|--------|--|-------|-----|-----|--------|---|
| 33.372DFA      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 33.372DFAK     | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 33.372DFAK     | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 35.372VF       | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 35.372VF       | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 35.372VF       | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 35.372VF       | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 35.372VFK      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 35.372VFK      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 35.372VFK      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 35.372VFK      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 40.372DFA      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 40.372DFA      | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 41.372VF       | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 41.372VF       | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 41.372VFAK     | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 41.372VFAK     | 01/93- | Diesel |  | 11995 | 272 | 370 | 06.86- | ■ |
| 19.4022FA      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 19.4022FA      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 19.402FAK      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 19.402FAK      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 19.402FAS      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 19.402FAS      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 26.402DF/DFL   | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 26.402DF/DFL   | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 26.402DFK/DFLK | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 26.402DFK/DFLK | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 26.402DFS      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 26.402DFS      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 33.402DFA      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 33.402DFA      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 33.402DFAK     | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 33.402DFAK     | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 35.402VF       | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 35.402VF       | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 35.402VF       | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 35.402VF       | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 35.402VFK      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 35.402VFK      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 35.402VFK      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 35.402VFK      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 40.402DFA      | 01/95- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 40.402DFA      | 01/95- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 41.4022VF      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 41.4022VF      | 01/94- | Diesel |  | 11995 | 294 | 400 | 06.86- | ■ |
| 19.422FA       | 01/93- | Diesel |  | 11995 | 309 | 420 | 06.86- | ■ |
| 19.422FA       | 01/93- | Diesel |  | 11995 | 309 | 420 | 06.86- | ■ |
| 19.422FAK      | 01/93- | Diesel |  | 11995 | 309 | 420 | 06.86- | ■ |
| 19.422FAK      | 01/93- | Diesel |  | 11995 | 309 | 420 | 06.86- | ■ |
| 19.422FAS      | 01/93- | Diesel |  | 11995 | 309 | 420 | 06.86- | ■ |
| 19.422FAS      | 01/93- | Diesel |  | 11995 | 309 | 420 | 06.86- | ■ |

# LISTA DE APLICACIONES - BUYERS GUIDE

|                                      |        |        |  |       |                         |     |             |   |
|--------------------------------------|--------|--------|--|-------|-------------------------|-----|-------------|---|
| 26.422DF/DFL                         | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 26.422DF/DFL                         | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 26.422DFK                            | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 26.422DFK                            | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 26.422DFS                            | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 26.422DFS                            | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 33.422DFA                            | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 33.422DFA                            | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 33.422DFAK                           | 01/94- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 33.422DFAK                           | 01/94- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 35.422VF                             | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 35.422VF                             | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 35.422VF                             | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 35.422VF                             | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 35.422VF                             | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 35.422VF                             | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 35.422VFK                            | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 35.422VFK                            | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 40.422DFA                            | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 40.422DFA                            | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 41.422VF                             | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 41.422VF                             | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 41.422VFAK                           | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 41.422VFAK                           | 01/93- | Diesel |  | 11995 | 309                     | 420 | 06.86-      | ■ |
| 48.502VFA                            | 01/93- | Diesel |  | 11995 | 368                     | 500 | 06.86-      | ■ |
| 48.502VFA                            | 01/93- | Diesel |  | 11995 | 368                     | 500 | 06.86-      | ■ |
| 48.502VFAK                           | 01/93- | Diesel |  | 11995 | 368                     | 500 | 06.86-      | ■ |
| 48.502VFAK                           | 01/93- | Diesel |  | 11995 | 368                     | 500 | 06.86-      | ■ |
| 27.502 DF/DFS                        | 01/00- | Diesel |  | 18195 | 368                     | 500 | 06.86-      | ■ |
| 27.502 DF/DFS                        | 01/00- | Diesel |  | 18195 | 368                     | 500 | 06.86-      | ■ |
| 33.502DFA                            | 01/93- | Diesel |  | 18295 | 368                     | 500 | 06.86-      | ■ |
| 33.502DFA                            | 01/93- | Diesel |  | 18295 | 368                     | 500 | 06.86-      | ■ |
| 40.502DFA                            | 01/93- | Diesel |  | 18295 | 368                     | 500 | 06.86-      | ■ |
| 40.502DFA                            | 01/93- | Diesel |  | 18295 | 368                     | 500 | 06.86-      | ■ |
| <b>F90 06.86-12.97</b>               |        |        |  |       | <b>Platform/Chassis</b> |     |             |   |
| 26.502 DF (D 2840 LF01)              | 01/93- | Diesel |  | 18273 | 368                     | 500 | 02.90-06.96 | ■ |
| 26.502 DF (D 2840 LF01)              | 01/93- | Diesel |  | 18273 | 368                     | 500 | 02.90-06.96 | ■ |
| 26.502 DF (D 2840 LF04)              | 01/93- | Diesel |  | 18273 | 368                     | 500 | 02.90-06.96 | ■ |
| 26.502 DF (D 2840 LF04)              | 01/93- | Diesel |  | 18273 | 368                     | 500 | 02.90-06.96 | ■ |
| 26.502 DF (D 2840 LF06)              | 01/93- | Diesel |  | 18273 | 368                     | 500 | 02.90-06.96 | ■ |
| 26.502 DF (D 2840 LF06)              | 01/93- | Diesel |  | 18273 | 368                     | 500 | 02.90-06.96 | ■ |
| <b>F90 06.86-12.97</b>               |        |        |  |       | <b>Truck Tractor</b>    |     |             |   |
| 26.502 DFS,26.502 DFLS (D 2840 LF04) | 01/93- | Diesel |  | 18273 | 368                     | 500 | 02.90-06.96 | ■ |
| 26.502 DFS,26.502 DFLS (D 2840 LF04) | 01/93- | Diesel |  | 18273 | 368                     | 500 | 02.90-06.96 | ■ |
| 26.502 DFS,26.502 DFLS (D 2840 LF06) | 01/93- | Diesel |  | 18273 | 368                     | 500 | 02.90-06.96 | ■ |
| 26.502 DFS,26.502 DFLS (D 2840 LF06) | 01/93- | Diesel |  | 18273 | 368                     | 500 | 02.90-06.96 | ■ |
| <b>M 2000 L 04.95-</b>               |        |        |  |       |                         |     |             |   |
| 15.163LK                             | 01/95- | Diesel |  | 4595  | 114                     | 155 | 04.95-      | ■ |
| 15.163LK                             | 01/95- | Diesel |  | 4595  | 114                     | 155 | 04.95-      | ■ |
| 15.224LK                             | 01/95- | Diesel |  | 6895  | 162                     | 220 | 04.95-      | ■ |

# LISTA DE APLICACIONES - BUYERS GUIDE

|                        |        |        |  |      |     |     |        |   |
|------------------------|--------|--------|--|------|-----|-----|--------|---|
| 15.224LK               | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224LAC              | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224LAC              | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224LAK              | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224LAK              | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224LK/LLK           | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224LK/LLK           | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224MAC              | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224MAC              | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224MAK              | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224MAK              | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224MK/MLK           | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 18.224MK/MLK           | 01/95- | Diesel |  | 6895 | 162 | 220 | 04.95- | ■ |
| 15.264LK               | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 15.264LK               | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 18.264LAK              | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 18.264LAK              | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 18.264LK/LLK           | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 18.264LK/LLK           | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 18.264MAC              | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 18.264MAC              | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 18.264MAK              | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 18.264MAK              | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 18.264MK/MLK           | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 18.264MK/MLK           | 01/95- | Diesel |  | 6895 | 191 | 260 | 04.95- | ■ |
| 15.284LK               | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 15.284LK               | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284LAC              | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284LAC              | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284LAK              | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284LAK              | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284LK/LLK           | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284LK/LLK           | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284MAC              | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284MAC              | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284MAK              | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284MAK              | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284MK/MLK           | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| 18.284MK/MLK           | 01/98- | Diesel |  | 6895 | 206 | 280 | 04.95- | ■ |
| <b>M90 08.88-12.98</b> |        |        |  |      |     |     |        |   |
| 17.192F/FL             | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |
| 17.192F/FL             | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |
| 17.192FA               | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |
| 17.192FA               | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |
| 17.192FAK              | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |
| 17.192FAK              | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |
| 17.192FS/FLS           | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |
| 17.192FS/FLS           | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |
| 18.192F/FL/FLL         | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |
| 18.192F/FL/FLL         | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |
| 18.192FK               | 01/93- | Diesel |  | 6895 | 140 | 190 | 08.88- | ■ |

# LISTA DE APLICACIONES - BUYERS GUIDE

|                |        |        |  |       |     |     |        |   |
|----------------|--------|--------|--|-------|-----|-----|--------|---|
| 18.192FK       | 01/93- | Diesel |  | 6895  | 140 | 190 | 08.88- | ■ |
| 24.192FNL/FNLL | 01/93- | Diesel |  | 6895  | 140 | 190 | 08.88- | ■ |
| 24.192FNL/FNLL | 01/93- | Diesel |  | 6895  | 140 | 190 | 08.88- | ■ |
| 17.232F/FL     | 01/93- | Diesel |  | 6895  | 160 | 218 | 08.88- | ■ |
| 17.232F/FL     | 01/93- | Diesel |  | 6895  | 160 | 218 | 08.88- | ■ |
| 17.232FA       | 01/93- | Diesel |  | 6895  | 160 | 218 | 08.88- | ■ |
| 17.232FA       | 01/93- | Diesel |  | 6895  | 160 | 218 | 08.88- | ■ |
| 17.232FAK      | 01/93- | Diesel |  | 6895  | 160 | 218 | 08.88- | ■ |
| 17.232FAK      | 01/93- | Diesel |  | 6895  | 160 | 218 | 08.88- | ■ |
| 17.232FS/FLS   | 01/93- | Diesel |  | 6895  | 160 | 218 | 08.88- | ■ |
| 17.232FS/FLS   | 01/93- | Diesel |  | 6895  | 160 | 218 | 08.88- | ■ |
| 24.232FNL      | 01/93- | Diesel |  | 6895  | 160 | 218 | 08.88- | ■ |
| 24.232FNL      | 01/93- | Diesel |  | 6895  | 160 | 218 | 08.88- | ■ |
| 17.222FA       | 01/94- | Diesel |  | 6895  | 162 | 220 | 08.88- | ■ |
| 17.222FA       | 01/94- | Diesel |  | 6895  | 162 | 220 | 08.88- | ■ |
| 17.222FAK      | 01/94- | Diesel |  | 6895  | 162 | 220 | 08.88- | ■ |
| 17.222FAK      | 01/94- | Diesel |  | 6895  | 162 | 220 | 08.88- | ■ |
| 18.222F/FL/FLL | 01/94- | Diesel |  | 6895  | 162 | 220 | 08.88- | ■ |
| 18.222F/FL/FLL | 01/94- | Diesel |  | 6895  | 162 | 220 | 08.88- | ■ |
| 18.222FK       | 01/94- | Diesel |  | 6895  | 162 | 220 | 08.88- | ■ |
| 18.222FK       | 01/94- | Diesel |  | 6895  | 162 | 220 | 08.88- | ■ |
| 24.222FNL/FNLL | 01/94- | Diesel |  | 6895  | 162 | 220 | 08.88- | ■ |
| 24.222FNL/FNLL | 01/94- | Diesel |  | 6895  | 162 | 220 | 08.88- | ■ |
| 17.192FS/FLS   | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 17.192FS/FLS   | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 17.232F/FL     | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 17.232F/FL     | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 17.232FA       | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 17.232FA       | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 17.232FAK      | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 17.232FAK      | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 18.232F/FL/FLL | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 18.232F/FL/FLL | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 18.232FK       | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 18.232FK       | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 24.232FNL/FNLL | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 24.232FNL/FNLL | 01/93- | Diesel |  | 6895  | 169 | 230 | 08.88- | ■ |
| 18.262F/FL/FLL | 01/95- | Diesel |  | 6895  | 191 | 260 | 08.88- | ■ |
| 18.262F/FL/FLL | 01/95- | Diesel |  | 6895  | 191 | 260 | 08.88- | ■ |
| 18.262FK       | 01/95- | Diesel |  | 6895  | 191 | 260 | 08.88- | ■ |
| 18.262FK       | 01/95- | Diesel |  | 6895  | 191 | 260 | 08.88- | ■ |
| 17.272FLS      | 01/93- | Diesel |  | 6895  | 198 | 269 | 08.88- | ■ |
| 17.272FLS      | 01/93- | Diesel |  | 6895  | 198 | 269 | 08.88- | ■ |
| 18.272F/FL/FLL | 01/93- | Diesel |  | 6895  | 198 | 269 | 08.88- | ■ |
| 18.272F/FL/FLL | 01/93- | Diesel |  | 6895  | 198 | 269 | 08.88- | ■ |
| 18.272FK       | 01/93- | Diesel |  | 6895  | 198 | 269 | 08.88- | ■ |
| 18.272FK       | 01/93- | Diesel |  | 6895  | 198 | 269 | 08.88- | ■ |
| 24.272FNL/FNLL | 01/93- | Diesel |  | 6895  | 198 | 269 | 08.88- | ■ |
| 24.272FNL/FNLL | 01/93- | Diesel |  | 6895  | 198 | 269 | 08.88- | ■ |
| 17.272FLS      | 01/93- | Diesel |  | 10000 | 198 | 269 | 08.88- | ■ |
| 17.272FLS      | 01/93- | Diesel |  | 10000 | 198 | 269 | 08.88- | ■ |

# LISTA DE APLICACIONES - BUYERS GUIDE

|                          |        |        |  |       |                          |     |             |   |
|--------------------------|--------|--------|--|-------|--------------------------|-----|-------------|---|
| 18.272F/FL/FLL           | 01/93- | Diesel |  | 10000 | 198                      | 269 | 08.88-      | ■ |
| 18.272F/FL/FLL           | 01/93- | Diesel |  | 10000 | 198                      | 269 | 08.88-      | ■ |
| 18.272FK                 | 01/93- | Diesel |  | 10000 | 198                      | 269 | 08.88-      | ■ |
| 18.272FK                 | 01/93- | Diesel |  | 10000 | 198                      | 269 | 08.88-      | ■ |
| 24.272FNL/FNLL           | 01/93- | Diesel |  | 10000 | 198                      | 269 | 08.88-      | ■ |
| 24.272FNL/FNLL           | 01/93- | Diesel |  | 10000 | 198                      | 269 | 08.88-      | ■ |
| MERCEDES-BENZ            |        |        |  |       |                          |     |             |   |
| <b>ATEGO 01.98-10.04</b> |        |        |  |       | <b>Concrete Mixer</b>    |     |             |   |
| 1325 AF (OM 906.919)     |        | Diesel |  | 6374  | 180                      | 244 | 01.98-10.04 | ■ |
| 1325 AF (OM 906.919)     |        | Diesel |  | 6374  | 180                      | 244 | 01.98-10.04 | ■ |
| 1325 AF (OM 906.939)     |        | Diesel |  | 6374  | 180                      | 244 | 01.98-10.04 | ■ |
| 1325 AF (OM 906.939)     |        | Diesel |  | 6374  | 180                      | 244 | 01.98-10.04 | ■ |
| <b>ATEGO 01.98-10.04</b> |        |        |  |       | <b>Dump Truck</b>        |     |             |   |
| 1317AK (OM 900.913)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1317AK (OM 900.913)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1317AK (OM 904.911)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1317AK (OM 904.911)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1317AK (OM 904.917)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1317AK (OM 904.917)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1523 AK (OM 906.910)     |        | Diesel |  | 6374  | 170                      | 231 | 01.98-10.04 | ■ |
| 1523 AK (OM 906.910)     |        | Diesel |  | 6374  | 170                      | 231 | 01.98-10.04 | ■ |
| 1523 AK (OM 906.915)     |        | Diesel |  | 6374  | 170                      | 231 | 01.98-10.04 | ■ |
| 1523 AK (OM 906.915)     |        | Diesel |  | 6374  | 170                      | 231 | 01.98-10.04 | ■ |
| <b>ATEGO 01.98-10.04</b> |        |        |  |       | <b>Municipal Vehicle</b> |     |             |   |
| 1225 AF (OM 906.919)     |        | Diesel |  | 6374  | 180                      | 245 | 01.98-10.04 | ■ |
| 1225 AF (OM 906.919)     |        | Diesel |  | 6374  | 180                      | 245 | 01.98-10.04 | ■ |
| 1225 AF (OM 906.939)     |        | Diesel |  | 6374  | 180                      | 245 | 01.98-10.04 | ■ |
| 1225 AF (OM 906.939)     |        | Diesel |  | 6374  | 180                      | 245 | 01.98-10.04 | ■ |
| 1525 AF (OM 906.919)     |        | Diesel |  | 6374  | 180                      | 245 | 01.98-10.04 | ■ |
| 1525 AF (OM 906.919)     |        | Diesel |  | 6374  | 180                      | 245 | 01.98-10.04 | ■ |
| 1525 AF (OM 906.939)     |        | Diesel |  | 6374  | 180                      | 245 | 01.98-10.04 | ■ |
| 1525 AF (OM 906.939)     |        | Diesel |  | 6374  | 180                      | 245 | 01.98-10.04 | ■ |
| 1328 AF (OM 906.911)     |        | Diesel |  | 6374  | 205                      | 279 | 01.98-10.04 | ■ |
| 1328 AF (OM 906.911)     |        | Diesel |  | 6374  | 205                      | 279 | 01.98-10.04 | ■ |
| 1328 AF (OM 906.916)     |        | Diesel |  | 6374  | 205                      | 279 | 01.98-10.04 | ■ |
| 1328 AF (OM 906.916)     |        | Diesel |  | 6374  | 205                      | 279 | 01.98-10.04 | ■ |
| 1528 AF (OM 906.911)     |        | Diesel |  | 6374  | 205                      | 279 | 01.98-10.04 | ■ |
| 1528 AF (OM 906.911)     |        | Diesel |  | 6374  | 205                      | 279 | 01.98-10.04 | ■ |
| 1528 AF (OM 906.916)     |        | Diesel |  | 6374  | 205                      | 279 | 01.98-10.04 | ■ |
| 1528 AF (OM 906.916)     |        | Diesel |  | 6374  | 205                      | 279 | 01.98-10.04 | ■ |
| <b>ATEGO 01.98-10.04</b> |        |        |  |       | <b>Platform/Chassis</b>  |     |             |   |
| 1317 A (OM 904.911)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1317 A (OM 904.911)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1317 A (OM 904.917)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1317 A (OM 904.917)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1517 A (OM 904.911)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1517 A (OM 904.911)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1517 A (OM 904.917)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1517 A (OM 904.917)      |        | Diesel |  | 4249  | 125                      | 170 | 01.98-10.04 | ■ |
| 1523 A (OM 906.910)      |        | Diesel |  | 6374  | 170                      | 231 | 01.98-10.04 | ■ |

# LISTA DE APLICACIONES - BUYERS GUIDE

|                                |        |        |  |       |                          |     |             |   |   |
|--------------------------------|--------|--------|--|-------|--------------------------|-----|-------------|---|---|
| 1523 A (OM 906.910)            |        | Diesel |  | 6374  | 170                      | 231 | 01.98-10.04 | ■ |   |
| 1523 A (OM 906.915)            |        | Diesel |  | 6374  | 170                      | 231 | 01.98-10.04 | ■ |   |
| 1523 A (OM 906.915)            |        | Diesel |  | 6374  | 170                      | 231 | 01.98-10.04 | ■ |   |
| <b>MK 12.87-12.05</b>          |        |        |  |       | <b>Dump Truck</b>        |     |             |   |   |
| 1827 K (OM 445.926)            |        | Diesel |  | 10964 | 200                      | 272 | 01.94-09.96 | ■ |   |
| 1827 K (OM 445.926)            |        | Diesel |  | 10964 | 200                      | 272 | 01.94-09.96 | ■ |   |
| <b>MK 12.87-12.05</b>          |        |        |  |       | <b>Municipal Vehicle</b> |     |             |   |   |
| 1231 AF (OM 401.986)           | -12/92 | Diesel |  | 9570  | 230                      | 313 | 01.92-09.96 | ■ |   |
| 1231 AF (OM 401.986)           | -12/92 | Diesel |  | 9570  | 230                      | 313 | 01.92-09.96 | ■ |   |
| 1227 AF, 1227 LAF (OM 445.933) |        | Diesel |  | 10964 | 200                      | 272 | 01.92-07.92 | ■ |   |
| 1227 AF, 1227 LAF (OM 445.933) |        | Diesel |  | 10964 | 200                      | 272 | 01.92-07.92 | ■ |   |
| 1627 AF (OM 442.914)           |        | Diesel |  | 15078 | 195                      | 265 | 01.92-09.96 | ■ | ■ |
| 1627 AF (OM 442.914)           |        | Diesel |  | 15078 | 195                      | 265 | 01.92-09.96 | ■ | ■ |
| 1627 AF (OM 442.920)           |        | Diesel |  | 15078 | 195                      | 265 | 01.92-09.96 | ■ | ■ |
| 1627 AF (OM 442.920)           |        | Diesel |  | 15078 | 195                      | 265 | 01.92-09.96 | ■ | ■ |
| 1627 AF (OM 442.932)           |        | Diesel |  | 15078 | 195                      | 265 | 01.92-09.96 | ■ | ■ |
| 1627 AF (OM 442.932)           |        | Diesel |  | 15078 | 195                      | 265 | 01.92-09.96 | ■ | ■ |
| 1627 AF (OM 442.933)           |        | Diesel |  | 15078 | 195                      | 265 | 01.92-09.96 | ■ | ■ |
| 1627 AF (OM 442.933)           |        | Diesel |  | 15078 | 195                      | 265 | 01.92-09.96 | ■ | ■ |
| 1429 AF (OM 442.926)           |        | Diesel |  | 15078 | 213                      | 290 | 01.92-09.96 | ■ | ■ |
| 1429 AF (OM 442.926)           |        | Diesel |  | 15078 | 213                      | 290 | 01.92-09.96 | ■ | ■ |
| <b>MK 12.87-12.05</b>          |        |        |  |       | <b>Platform/Chassis</b>  |     |             |   |   |
| 1417                           | 01/93- | Diesel |  | 5995  | 121                      | 165 | 07.89-09.96 | ■ | ■ |
| 1417                           | 01/93- | Diesel |  | 5995  | 121                      | 165 | 07.89-09.96 | ■ | ■ |
| 1417A                          | 01/93- | Diesel |  | 5995  | 121                      | 165 | 12.87-      | ■ | ■ |
| 1417A                          | 01/93- | Diesel |  | 5995  | 121                      | 165 | 12.87-      | ■ | ■ |
| 1417AK                         | 01/93- | Diesel |  | 5995  | 121                      | 165 | 12.87-      | ■ | ■ |
| 1417AK                         | 01/93- | Diesel |  | 5995  | 121                      | 165 | 12.87-      | ■ | ■ |
| 1417K                          | 01/93- | Diesel |  | 5995  | 121                      | 165 | 12.87-      | ■ | ■ |
| 1417K                          | 01/93- | Diesel |  | 5995  | 121                      | 165 | 12.87-      | ■ | ■ |
| 1717AK                         | 01/93- | Diesel |  | 5995  | 129                      | 175 | 12.87-      | ■ |   |
| 1717AK                         | 01/93- | Diesel |  | 5995  | 129                      | 175 | 12.87-      | ■ |   |
| 1420/L                         | 01/93- | Diesel |  | 5995  | 155                      | 211 | 12.87-      | ■ | ■ |
| 1420/L                         | 01/93- | Diesel |  | 5995  | 155                      | 211 | 12.87-      | ■ | ■ |
| 1420LS                         | 01/93- | Diesel |  | 5995  | 155                      | 211 | 12.87-      | ■ | ■ |
| 1420LS                         | 01/93- | Diesel |  | 5995  | 155                      | 211 | 12.87-      | ■ | ■ |
| 1820AK                         | 01/93- | Diesel |  | 5995  | 155                      | 211 | 12.87-      | ■ |   |
| 1820AK                         | 01/93- | Diesel |  | 5995  | 155                      | 211 | 12.87-      | ■ |   |
| 1820K                          | 01/93- | Diesel |  | 5995  | 155                      | 211 | 12.87-      | ■ |   |
| 1820K                          | 01/93- | Diesel |  | 5995  | 155                      | 211 | 12.87-      | ■ |   |
| 1422F                          | 01/93- | Diesel |  | 5995  | 177                      | 220 | 12.87-      | ■ | ■ |
| 1422F                          | 01/93- | Diesel |  | 5995  | 177                      | 220 | 12.87-      | ■ | ■ |
| 1722AK                         | 01/93- | Diesel |  | 5995  | 177                      | 241 | 12.87-      | ■ |   |
| 1722AK                         | 01/93- | Diesel |  | 5995  | 177                      | 241 | 12.87-      | ■ |   |
| 1422F                          | 01/93- | Diesel |  | 9595  | 180                      | 220 | 12.87-      | ■ | ■ |
| 1422F                          | 01/93- | Diesel |  | 9595  | 180                      | 220 | 12.87-      | ■ | ■ |
| 1424/L                         | 01/93- | Diesel |  | 9595  | 180                      | 245 | 12.87-      | ■ | ■ |
| 1424/L                         | 01/93- | Diesel |  | 9595  | 180                      | 245 | 12.87-      | ■ | ■ |
| 1424S/LS                       | 01/93- | Diesel |  | 9595  | 180                      | 245 | 12.87-      | ■ | ■ |
| 1424S/LS                       | 01/93- | Diesel |  | 9595  | 180                      | 245 | 12.87-      | ■ | ■ |

# LISTA DE APLICACIONES - BUYERS GUIDE

|          |        |        |  |       |     |     |        |   |   |
|----------|--------|--------|--|-------|-----|-----|--------|---|---|
| 1820AK   | 01/93- | Diesel |  | 9595  | 180 | 245 | 12.87- | ■ |   |
| 1820AK   | 01/93- | Diesel |  | 9595  | 180 | 245 | 12.87- | ■ |   |
| 1824K    | 01/93- | Diesel |  | 9595  | 180 | 245 | 12.87- | ■ |   |
| 1824K    | 01/93- | Diesel |  | 9595  | 180 | 245 | 12.87- | ■ |   |
| 2024     | 01/93- | Diesel |  | 9595  | 180 | 245 | 12.87- | ■ |   |
| 2024     | 01/93- | Diesel |  | 9595  | 180 | 245 | 12.87- | ■ |   |
| 2024AK   | 01/93- | Diesel |  | 9595  | 180 | 245 | 12.87- | ■ |   |
| 2024AK   | 01/93- | Diesel |  | 9595  | 180 | 245 | 12.87- | ■ |   |
| 2024K    | 01/93- | Diesel |  | 9595  | 180 | 245 | 12.87- | ■ |   |
| 2024K    | 01/93- | Diesel |  | 9595  | 180 | 245 | 12.87- | ■ |   |
| 1422LS   | 01/93- | Diesel |  | 9595  | 200 | 220 | 12.87- | ■ | ■ |
| 1422LS   | 01/93- | Diesel |  | 9595  | 200 | 220 | 12.87- | ■ | ■ |
| 1427F    | 01/93- | Diesel |  | 9595  | 200 | 272 | 12.87- | ■ | ■ |
| 1427F    | 01/93- | Diesel |  | 9595  | 200 | 272 | 12.87- | ■ | ■ |
| 1722AK   | 01/93- | Diesel |  | 9595  | 200 | 272 | 12.87- | ■ |   |
| 1722AK   | 01/93- | Diesel |  | 9595  | 200 | 272 | 12.87- | ■ |   |
| 1422     | 01/93- | Diesel |  | 9595  | 230 | 218 | 12.87- | ■ | ■ |
| 1422     | 01/93- | Diesel |  | 9595  | 230 | 218 | 12.87- | ■ | ■ |
| 1831AK   | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 1831AK   | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 1831K    | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 1831K    | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2031     | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2031     | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2031A    | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2031A    | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2031AS   | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2031AS   | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2031S    | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2031S    | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2631A    | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2631A    | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2631AK   | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2631AK   | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2631AS   | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 2631AS   | 01/93- | Diesel |  | 9595  | 230 | 313 | 12.87- | ■ |   |
| 1424/L   | 01/95- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ | ■ |
| 1424/L   | 01/95- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ | ■ |
| 1424S/LS | 01/95- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ | ■ |
| 1424S/LS | 01/95- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ | ■ |
| 1824AK   | 01/94- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ |   |
| 1824AK   | 01/94- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ |   |
| 1824K    | 01/94- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ |   |
| 1824K    | 01/94- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ |   |
| 2024     | 01/94- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ |   |
| 2024     | 01/94- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ |   |
| 2024AK   | 01/94- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ |   |
| 2024AK   | 01/94- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ |   |
| 2024K    | 01/94- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ |   |
| 2024K    | 01/94- | Diesel |  | 10995 | 180 | 245 | 12.87- | ■ |   |
| 1831AK   | 01/94- | Diesel |  | 10995 | 230 | 313 | 12.87- | ■ |   |

# LISTA DE APLICACIONES - BUYERS GUIDE

|          |                        |        |  |       |     |     |        |   |   |
|----------|------------------------|--------|--|-------|-----|-----|--------|---|---|
| 1831AK   | 01/94-                 | Diesel |  | 10995 | 230 | 313 | 12.87- | ■ |   |
| 1831K    | 01/93-                 | Diesel |  | 10995 | 230 | 313 | 12.87- | ■ |   |
| 1831K    | 01/93-                 | Diesel |  | 10995 | 230 | 313 | 12.87- | ■ |   |
| 2031A    | 01/94-                 | Diesel |  | 10995 | 230 | 313 | 12.87- | ■ |   |
| 2031A    | 01/94-                 | Diesel |  | 10995 | 230 | 313 | 12.87- | ■ |   |
| 2631A    | 01/94-                 | Diesel |  | 10995 | 230 | 313 | 12.87- | ■ |   |
| 2631A    | 01/94-                 | Diesel |  | 10995 | 230 | 313 | 12.87- | ■ |   |
| 2631AK   | 01/94-                 | Diesel |  | 10995 | 230 | 313 | 12.87- | ■ |   |
| 2631AK   | 01/94-                 | Diesel |  | 10995 | 230 | 313 | 12.87- | ■ |   |
| 2534/L   | 01/93-, Auxiliary Axle | Diesel |  | 10995 | 250 | 340 | 12.87- |   | ■ |
| 2534/L   | 01/93-, Auxiliary Axle | Diesel |  | 10995 | 250 | 340 | 12.87- |   | ■ |
| 1722AK   | 01/93-                 | Diesel |  | 11295 | 151 | 205 | 12.87- | ■ |   |
| 1722AK   | 01/93-                 | Diesel |  | 11295 | 151 | 205 | 12.87- | ■ |   |
| 1422/L   | 01/93-                 | Diesel |  | 11295 | 160 | 218 | 12.87- | ■ | ■ |
| 1422/L   | 01/93-                 | Diesel |  | 11295 | 160 | 218 | 12.87- | ■ | ■ |
| 1422F    | 01/93-                 | Diesel |  | 11295 | 160 | 218 | 12.87- | ■ | ■ |
| 1422F    | 01/93-                 | Diesel |  | 11295 | 160 | 218 | 12.87- | ■ | ■ |
| 1422S/LS | 01/93-                 | Diesel |  | 11295 | 160 | 220 | 12.87- | ■ | ■ |
| 1422S/LS | 01/93-                 | Diesel |  | 11295 | 160 | 220 | 12.87- | ■ | ■ |
| 1922AK   | 01/93-                 | Diesel |  | 11295 | 160 | 218 | 12.87- | ■ |   |
| 1922AK   | 01/93-                 | Diesel |  | 11295 | 160 | 218 | 12.87- | ■ |   |
| 1838AK   | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 1838AK   | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 1838K    | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 1838K    | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2031A    | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2031A    | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2038     | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2038     | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2038AS   | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2038AS   | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2038S    | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2038S    | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2538     | 01/93-, Auxiliary Axle | Diesel |  | 12795 | 280 | 381 | 12.87- |   | ■ |
| 2538     | 01/93-, Auxiliary Axle | Diesel |  | 12795 | 280 | 381 | 12.87- |   | ■ |
| 2538/L   | 01/93-, Auxiliary Axle | Diesel |  | 12795 | 280 | 381 | 12.87- |   | ■ |
| 2538/L   | 01/93-, Auxiliary Axle | Diesel |  | 12795 | 280 | 381 | 12.87- |   | ■ |
| 2638AK   | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2638AK   | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2638AS   | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2638AS   | 01/93-                 | Diesel |  | 12795 | 280 | 381 | 12.87- | ■ |   |
| 2031A    | 01/93-                 | Diesel |  | 12795 | 320 | 435 | 12.87- | ■ |   |
| 2031A    | 01/93-                 | Diesel |  | 12795 | 320 | 435 | 12.87- | ■ |   |
| 1935AK   | 01/93-                 | Diesel |  | 14595 | 250 | 340 | 12.87- | ■ |   |
| 1935AK   | 01/93-                 | Diesel |  | 14595 | 250 | 340 | 12.87- | ■ |   |
| 1935AS   | 01/93-                 | Diesel |  | 14595 | 250 | 340 | 12.87- | ■ |   |
| 1935AS   | 01/93-                 | Diesel |  | 14595 | 250 | 340 | 12.87- | ■ |   |
| 1735AK   | 01/93-                 | Diesel |  | 14595 | 260 | 354 | 12.87- | ■ |   |
| 1735AK   | 01/93-                 | Diesel |  | 14595 | 260 | 354 | 12.87- | ■ |   |
| 2635AS   | 01/93-                 | Diesel |  | 14595 | 266 | 362 | 12.87- | ■ |   |
| 2635AS   | 01/93-                 | Diesel |  | 14595 | 266 | 362 | 12.87- | ■ |   |

# LISTA DE APLICACIONES - BUYERS GUIDE

|          |                        |        |  |       |     |     |        |   |   |
|----------|------------------------|--------|--|-------|-----|-----|--------|---|---|
| 1838AK   | 01/94-                 | Diesel |  | 14595 | 280 | 381 | 12.87- | ■ |   |
| 1838AK   | 01/94-                 | Diesel |  | 14595 | 280 | 381 | 12.87- | ■ |   |
| 2031A    | 01/94-                 | Diesel |  | 14595 | 280 | 381 | 12.87- | ■ |   |
| 2031A    | 01/94-                 | Diesel |  | 14595 | 280 | 381 | 12.87- | ■ |   |
| 2038AS   | 01/94-                 | Diesel |  | 14595 | 280 | 381 | 12.87- | ■ |   |
| 2038AS   | 01/94-                 | Diesel |  | 14595 | 280 | 381 | 12.87- | ■ |   |
| 2538/L   | 01/94-, Auxiliary Axle | Diesel |  | 14595 | 280 | 381 | 12.87- |   | ■ |
| 2538/L   | 01/94-, Auxiliary Axle | Diesel |  | 14595 | 280 | 381 | 12.87- |   | ■ |
| 2638AK   | 01/94-                 | Diesel |  | 14595 | 280 | 381 | 12.87- | ■ |   |
| 2638AK   | 01/94-                 | Diesel |  | 14595 | 280 | 381 | 12.87- | ■ |   |
| 2638AS   | 01/94-                 | Diesel |  | 14595 | 280 | 381 | 12.87- | ■ |   |
| 2638AS   | 01/94-                 | Diesel |  | 14595 | 280 | 381 | 12.87- | ■ |   |
| 1838AK   | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 1838AK   | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 1838K    | 01/95-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 1838K    | 01/95-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 20344S   | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 20344S   | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 2038AS   | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 2038AS   | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 2044     | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 2044     | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 2538/L   | 01/93-, Auxiliary Axle | Diesel |  | 14595 | 320 | 435 | 12.87- |   | ■ |
| 2538/L   | 01/93-, Auxiliary Axle | Diesel |  | 14595 | 320 | 435 | 12.87- |   | ■ |
| 2544/L   | 01/93-, Auxiliary Axle | Diesel |  | 14595 | 320 | 435 | 12.87- |   | ■ |
| 2544/L   | 01/93-, Auxiliary Axle | Diesel |  | 14595 | 320 | 435 | 12.87- |   | ■ |
| 2544S    | 01/93-, Auxiliary Axle | Diesel |  | 14595 | 320 | 435 | 12.87- |   | ■ |
| 2544S    | 01/93-, Auxiliary Axle | Diesel |  | 14595 | 320 | 435 | 12.87- |   | ■ |
| 2638AK   | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 2638AK   | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 2638AS   | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 2638AS   | 01/93-                 | Diesel |  | 14595 | 320 | 435 | 12.87- | ■ |   |
| 2050     | 01/93-                 | Diesel |  | 14595 | 362 | 492 | 12.87- | ■ |   |
| 2050     | 01/93-                 | Diesel |  | 14595 | 362 | 492 | 12.87- | ■ |   |
| 2050S    | 01/93-                 | Diesel |  | 14595 | 362 | 492 | 12.87- | ■ |   |
| 2050S    | 01/93-                 | Diesel |  | 14595 | 362 | 492 | 12.87- | ■ |   |
| 1838AK   | 01/93-                 | Diesel |  | 14595 | 370 | 503 | 12.87- | ■ |   |
| 1838AK   | 01/93-                 | Diesel |  | 14595 | 370 | 503 | 12.87- | ■ |   |
| 2538     | 01/93-, Auxiliary Axle | Diesel |  | 14595 | 370 | 503 | 12.87- |   | ■ |
| 2538     | 01/93-, Auxiliary Axle | Diesel |  | 14595 | 370 | 503 | 12.87- |   | ■ |
| 2550/L   | 01/93-, Auxiliary Axle | Diesel |  | 14595 | 370 | 503 | 12.87- |   | ■ |
| 2550/L   | 01/93-, Auxiliary Axle | Diesel |  | 14595 | 370 | 503 | 12.87- |   | ■ |
| 2638AK   | 01/93-                 | Diesel |  | 14595 | 370 | 503 | 12.87- | ■ |   |
| 2638AK   | 01/93-                 | Diesel |  | 14595 | 370 | 503 | 12.87- | ■ |   |
| 2638AS   | 01/93-                 | Diesel |  | 14595 | 370 | 503 | 12.87- | ■ |   |
| 2638AS   | 01/93-                 | Diesel |  | 14595 | 370 | 503 | 12.87- | ■ |   |
| 1853AK   | 01/96-                 | Diesel |  | 14595 | 390 | 530 | 12.87- | ■ |   |
| 1853AK   | 01/96-                 | Diesel |  | 14595 | 390 | 530 | 12.87- | ■ |   |
| 2553/L   | 01/96-, Auxiliary Axle | Diesel |  | 14595 | 390 | 530 | 12.87- |   | ■ |
| 2553/L   | 01/96-, Auxiliary Axle | Diesel |  | 14595 | 390 | 530 | 12.87- |   | ■ |
| 1426S/LS | 01/93-                 | Diesel |  | 15095 | 191 | 260 | 12.87- | ■ | ■ |

# LISTA DE APLICACIONES - BUYERS GUIDE

|                       |        |        |  |       |     |     |        |   |   |
|-----------------------|--------|--------|--|-------|-----|-----|--------|---|---|
| 1426S/LS              | 01/93- | Diesel |  | 15095 | 191 | 260 | 12.87- | ■ | ■ |
| 1726AK                | 01/93- | Diesel |  | 15095 | 195 | 265 | 12.87- | ■ |   |
| 1726AK                | 01/93- | Diesel |  | 15095 | 195 | 265 | 12.87- | ■ |   |
| 1929A                 | 01/93- | Diesel |  | 15095 | 210 | 286 | 12.87- | ■ |   |
| 1929A                 | 01/93- | Diesel |  | 15095 | 210 | 286 | 12.87- | ■ |   |
| 1929AK                | 01/93- | Diesel |  | 15095 | 210 | 286 | 12.87- | ■ |   |
| 1929AK                | 01/93- | Diesel |  | 15095 | 210 | 286 | 12.87- | ■ |   |
| 1729AK                | 01/93- | Diesel |  | 15095 | 213 | 290 | 12.87- | ■ |   |
| 1729AK                | 01/93- | Diesel |  | 15095 | 213 | 290 | 12.87- | ■ |   |
| 1929AS                | 01/93- | Diesel |  | 15095 | 213 | 290 | 12.87- | ■ |   |
| 1929AS                | 01/93- | Diesel |  | 15095 | 213 | 290 | 12.87- | ■ |   |
| 1929A                 | 01/93- | Diesel |  | 15095 | 269 | 366 | 12.87- | ■ |   |
| 1929A                 | 01/93- | Diesel |  | 15095 | 269 | 366 | 12.87- | ■ |   |
| 1929A                 | 01/93- | Diesel |  | 18295 | 340 | 462 | 12.87- | ■ |   |
| 1929A                 | 01/93- | Diesel |  | 18295 | 340 | 462 | 12.87- | ■ |   |
| <b>NG 08.73-03.98</b> |        |        |  |       |     |     |        |   |   |
| 3229B                 | 01/93- | Diesel |  | 14595 | 213 | 290 | 08.73- | ■ | ■ |
| 3229B                 | 01/93- | Diesel |  | 14595 | 213 | 290 | 08.73- | ■ | ■ |
| 3229K                 | 01/93- | Diesel |  | 14595 | 213 | 290 | 08.73- | ■ | ■ |
| 3229K                 | 01/93- | Diesel |  | 14595 | 213 | 290 | 08.73- | ■ | ■ |
| 3236A                 | 01/93- | Diesel |  | 14595 | 261 | 355 | 08.73- | ■ | ■ |
| 3236A                 | 01/93- | Diesel |  | 14595 | 261 | 355 | 08.73- | ■ | ■ |
| 3250A                 | 01/93- | Diesel |  | 18295 | 368 | 500 | 08.73- | ■ | ■ |
| 3250A                 | 01/93- | Diesel |  | 18295 | 368 | 500 | 08.73- | ■ | ■ |
| 3250AF                | 01/93- | Diesel |  | 18295 | 368 | 500 | 08.73- | ■ |   |
| 3250AF                | 01/93- | Diesel |  | 18295 | 368 | 500 | 08.73- | ■ |   |