


LISTA DE APLICACIONES - BUYERS GUIDE

30410-4844



8 424073 102966

Weight: 11.240



30410-4844



Ate - Teves

151.3x46.1x18

Ø239.5x24x58

WVA

20783

MAKE

FORD



Trac.

CC

Kw

CV



Front / Rear

FORD

ESCORT IV (ALF) 01.86-11.92

					Convertible (Compact car-C Segment)				
1.4 (F6B)		Gasolina	FWD	1392	54	73	02.87-07.90		■
1.4 (F6B)		Gasolina	FWD	1392	54	73	02.87-07.90		■
1.4 (F6D)		Gasolina	FWD	1392	54	73	02.87-07.90		■
1.4 (F6D)		Gasolina	FWD	1392	54	73	02.87-07.90		■
1.4 (FUC)		Gasolina	FWD	1392	54	73	02.87-07.90		■
1.4 (FUC)		Gasolina	FWD	1392	54	73	02.87-07.90		■
1.4 (FUA)		Gasolina	FWD	1392	55	75	01.86-07.90		■
1.4 (FUA)		Gasolina	FWD	1392	55	75	01.86-07.90		■
1.6 (LP2)		Gasolina	FWD	1597	58	79	01.86-12.87		■
1.6 (LP2)		Gasolina	FWD	1597	58	79	01.86-12.87		■
1.6 (LPA)		Gasolina	FWD	1597	58	79	01.86-12.87		■
1.6 (LPA)		Gasolina	FWD	1597	58	79	01.86-12.87		■
1.6 i (LJB)		Gasolina	FWD	1597	75	102	08.89-07.90		■
1.6 i (LJB)		Gasolina	FWD	1597	75	102	08.89-07.90		■
1.6 i (L4B)		Gasolina	FWD	1598	66	90	01.86-07.90		■
1.6 i (L4B)		Gasolina	FWD	1598	66	90	01.86-07.90		■

ESCORT IV (GAF, AWF, ABFT) 03.83-10.94

					Hatchback (Compact car-C Segment)				
1.3 (JPA)		Gasolina	FWD	1296	51	69	11.86-07.88		■
1.3 (JPA)		Gasolina	FWD	1296	51	69	11.86-07.88		■
1.6 (LP2)		Gasolina	FWD	1597	58	79	01.86-12.88		■
1.6 (LP2)		Gasolina	FWD	1597	58	79	01.86-12.88		■
1.6 i (LJB)		Gasolina	FWD	1597	75	102	08.89-07.90		■

LISTA DE APLICACIONES - BUYERS GUIDE

1.6 i (LJB)		Gasolina	FWD	1597	75	102	08.89-07.90	■
1.6 (LUG)		Gasolina	FWD	1598	65	88	04.89-07.90	■
1.6 (LUG)		Gasolina	FWD	1598	65	88	04.89-07.90	■
1.6 i (L4B)		Gasolina	FWD	1598	66	90	01.86-05.90	■
1.6 i (L4B)		Gasolina	FWD	1598	66	90	01.86-05.90	■
1.6 D (LTC)		Diesel	FWD	1608	40	54	01.86-01.89	■
1.6 D (LTC)		Diesel	FWD	1608	40	54	01.86-01.89	■
1.8 D (RTA)		Diesel	FWD	1753	44	60	01.89-07.90	■
1.8 D (RTA)		Diesel	FWD	1753	44	60	01.89-07.90	■
1.8 D (RTB)		Diesel	FWD	1753	44	60	01.89-07.90	■
1.8 D (RTB)		Diesel	FWD	1753	44	60	01.89-07.90	■
ESCORT IV Turnier (AWF, AVF) 10.85-10.90					Estate (Compact car-C Segment)			
1.4 (FUAA)		Gasolina	FWD	1392	51	70	10.85-10.90	■
1.4 (FUAA)		Gasolina	FWD	1392	51	70	10.85-10.90	■
1.4 (F6B)		Gasolina	FWD	1392	54	73	01.86-07.90	■
1.4 (F6B)		Gasolina	FWD	1392	54	73	01.86-07.90	■
1.4 (F6D)		Gasolina	FWD	1392	54	73	01.86-07.90	■
1.4 (F6D)		Gasolina	FWD	1392	54	73	01.86-07.90	■
1.4 (FUC)		Gasolina	FWD	1392	54	73	01.86-07.90	■
1.4 (FUC)		Gasolina	FWD	1392	54	73	01.86-07.90	■
1.4 (FUA)		Gasolina	FWD	1392	55	75	01.86-07.90	■
1.4 (FUA)		Gasolina	FWD	1392	55	75	01.86-07.90	■
1.6 (LP2)		Gasolina	FWD	1597	58	79	01.86-07.90	■
1.6 (LP2)		Gasolina	FWD	1597	58	79	01.86-07.90	■
1.6		Gasolina	FWD	1597	75	102	04.87-08.89	■
1.6		Gasolina	FWD	1597	75	102	04.87-08.89	■
1.6 i (L4B)		Gasolina	FWD	1598	66	90	01.86-07.90	■
1.6 i (L4B)		Gasolina	FWD	1598	66	90	01.86-07.90	■
1.8 D (RTA)		Diesel	FWD	1753	44	60	01.89-07.90	■
1.8 D (RTA)		Diesel	FWD	1753	44	60	01.89-07.90	■
1.8 D (RTB)		Diesel	FWD	1753	44	60	01.89-07.90	■
1.8 D (RTB)		Diesel	FWD	1753	44	60	01.89-07.90	■
ORION II (AFF) 12.85-07.90					Saloon (Compact car-C Segment)			
1.4 (FUAA)		Gasolina	FWD	1392	52	72	03.86-07.90	■
1.4 (FUAA)		Gasolina	FWD	1392	52	72	03.86-07.90	■
1.4 (FUC)		Gasolina	FWD	1392	54	73	01.86-07.90	■
1.4 (FUC)		Gasolina	FWD	1392	54	73	01.86-07.90	■
1.4 Cat (F6B)		Gasolina	FWD	1392	54	73	02.87-07.90	■
1.4 Cat (F6B)		Gasolina	FWD	1392	54	73	02.87-07.90	■
1.4 Cat (F6D)		Gasolina	FWD	1392	54	73	02.87-07.90	■
1.4 Cat (F6D)		Gasolina	FWD	1392	54	73	02.87-07.90	■
1.4 (FUA)		Gasolina	FWD	1392	55	75	12.85-07.90	■
1.4 (FUA)		Gasolina	FWD	1392	55	75	12.85-07.90	■
1.6 (LUG)		Gasolina	FWD	1597	65	88	03.86-07.90	■
1.6 (LUG)		Gasolina	FWD	1597	65	88	03.86-07.90	■
1.6 (LUC)		Gasolina	FWD	1597	66	90	12.85-07.90	■
1.6 (LUC)		Gasolina	FWD	1597	66	90	12.85-07.90	■
1.6 i Cat (L4B)		Gasolina	FWD	1597	66	90	03.86-07.90	■
1.6 i Cat (L4B)		Gasolina	FWD	1597	66	90	03.86-07.90	■
1.6 i (LJB)		Gasolina	FWD	1597	75	102	02.86-07.90	■
1.6 i (LJB)		Gasolina	FWD	1597	75	102	02.86-07.90	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.6 i (LRB)		Gasolina	FWD	1597	77	105	03.86-07.90	■
1.6 i (LRB)		Gasolina	FWD	1597	77	105	03.86-07.90	■
1.8 D (RTA)		Diesel	FWD	1753	44	60	01.89-07.90	■
1.8 D (RTA)		Diesel	FWD	1753	44	60	01.89-07.90	■
1.8 D (RTB)		Diesel	FWD	1753	44	60	01.89-07.90	■
1.8 D (RTB)		Diesel	FWD	1753	44	60	01.89-07.90	■
SIERRA II (GBC, GBG) 01.87-03.93					Hatchback (Large family car-D Segment)			
1.6 (LSF)	01/91-	Gasolina	RWD	1597	53	72	01.88-02.93	■
1.6 (LSF)	01/91-	Gasolina	RWD	1597	53	72	01.88-02.93	■
1.6 (LSE)	01/91-	Gasolina	RWD	1597	55	75	01.87-02.93	■
1.6 (LSE)	01/91-	Gasolina	RWD	1597	55	75	01.87-02.93	■
1.6 i (L6B)	01/91-	Gasolina	RWD	1598	59	80	10.89-02.93	■
1.6 i (L6B)	01/91-	Gasolina	RWD	1598	59	80	10.89-02.93	■
2.0 i (NE5)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i (NE5)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i (NEJ)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i (NEJ)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i Cat (N4B)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i Cat (N4B)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 (N8C)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 (N8C)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 (NES)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 (NES)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 i (N4A)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i (N4A)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i (N4I)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i (N4I)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i (N8A)	01/91-	Gasolina	RWD	1998	80	109	06.89-02.93	■
2.0 i (N8A)	01/91-	Gasolina	RWD	1998	80	109	06.89-02.93	■
2.0 i DOHC (N9E)		Gasolina	RWD	1998	85	115	12.91-02.93	■
2.0 i DOHC (N9E)		Gasolina	RWD	1998	85	115	12.91-02.93	■
2.0 4x4 (N9C)		Gasolina	4WD	1998	88	120	10.91-03.93	■
2.0 4x4 (N9C)		Gasolina	4WD	1998	88	120	10.91-03.93	■
2.0 i (N9C)	01/91-	Gasolina	RWD	1998	88	120	06.89-02.93	■
2.0 i (N9C)	01/91-	Gasolina	RWD	1998	88	120	06.89-02.93	■
2.0 i (N9B)	01/91-	Gasolina	RWD	1998	92	125	06.89-02.93	■
2.0 i (N9B)	01/91-	Gasolina	RWD	1998	92	125	06.89-02.93	■
1.8 TD (RFA)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFA)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFB)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFB)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFL)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFL)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
SIERRA II (GBG, GB4) 01.87-02.93					Saloon (Large family car-D Segment)			
1.6 (LSF)	01/91-	Gasolina	RWD	1597	53	72	01.88-02.93	■
1.6 (LSF)	01/91-	Gasolina	RWD	1597	53	72	01.88-02.93	■
1.6 (LSE)	01/91-	Gasolina	RWD	1597	55	75	01.87-02.93	■
1.6 (LSE)	01/91-	Gasolina	RWD	1597	55	75	01.87-02.93	■
1.8 (R2C)	01/91-	Gasolina	RWD	1769	64	87	05.88-02.93	■
1.8 (R2C)	01/91-	Gasolina	RWD	1769	64	87	05.88-02.93	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.8 (R6A)	01/91-	Gasolina	RWD	1769	64	87	05.88-02.93	■
1.8 (R6A)	01/91-	Gasolina	RWD	1769	64	87	05.88-02.93	■
2.0 i (NE5)		Gasolina	RWD	1993	74	100	01.87-12.89	■
2.0 i (NE5)		Gasolina	RWD	1993	74	100	01.87-12.89	■
2.0 i (NEJ)		Gasolina	RWD	1993	74	100	01.87-12.89	■
2.0 i (NEJ)		Gasolina	RWD	1993	74	100	01.87-12.89	■
2.0 i Cat (N4B)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i Cat (N4B)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 (N8C)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 (N8C)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 (NES)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 (NES)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 i (N4A)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i (N4A)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i (N4I)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i (N4I)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 (N8A)	01/91-	Gasolina	RWD	1998	80	109	07.89-12.92	■
2.0 (N8A)	01/91-	Gasolina	RWD	1998	80	109	07.89-12.92	■
2.0 i DOHC (N9E)		Gasolina	RWD	1998	85	115	12.91-02.93	■
2.0 i DOHC (N9E)		Gasolina	RWD	1998	85	115	12.91-02.93	■
2.0 4x4 (N9C)		Gasolina	4WD	1998	88	120	01.90-02.93	■
2.0 4x4 (N9C)		Gasolina	4WD	1998	88	120	01.90-02.93	■
2.0 i (N9C)		Gasolina	RWD	1998	88	120	01.90-02.93	■
2.0 i (N9C)		Gasolina	RWD	1998	88	120	01.90-02.93	■
2.0 4x4 (N9C)	01/91-	Gasolina	4WD	1998	92	125	01.90-02.93	■
2.0 4x4 (N9C)	01/91-	Gasolina	4WD	1998	92	125	01.90-02.93	■
2.0 i (N9C)	01/91-	Gasolina	RWD	1998	92	125	01.90-02.93	■
2.0 i (N9C)	01/91-	Gasolina	RWD	1998	92	125	01.90-02.93	■
1.8 TD (RFA)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFA)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFB)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFB)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFL)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFL)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
SIERRA II Turnier (BNG) 01.87-02.93					Estate (Large family car-D Segment)			
1.6 (LSF)	01/91-	Gasolina	RWD	1597	53	72	01.88-02.93	■
1.6 (LSF)	01/91-	Gasolina	RWD	1597	53	72	01.88-02.93	■
1.6 (LSE)	01/91-	Gasolina	RWD	1597	55	75	01.87-02.93	■
1.6 (LSE)	01/91-	Gasolina	RWD	1597	55	75	01.87-02.93	■
1.6 i (L6B)	01/91-	Gasolina	RWD	1598	59	80	10.89-02.93	■
1.6 i (L6B)	01/91-	Gasolina	RWD	1598	59	80	10.89-02.93	■
1.8 (R2C)	01/91-	Gasolina	RWD	1769	64	87	05.88-02.93	■
1.8 (R2C)	01/91-	Gasolina	RWD	1769	64	87	05.88-02.93	■
1.8 (R6A)	01/91-	Gasolina	RWD	1769	64	87	05.88-02.93	■
1.8 (R6A)	01/91-	Gasolina	RWD	1769	64	87	05.88-02.93	■
2.0 i (NE5)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i (NE5)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i (NEJ)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i (NEJ)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i Cat (N4B)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■
2.0 i Cat (N4B)	01/91-	Gasolina	RWD	1993	74	100	01.87-02.93	■

LISTA DE APLICACIONES - BUYERS GUIDE

2.0 (N8C)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 (N8C)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 (NES)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 (NES)	01/91-	Gasolina	RWD	1993	77	105	01.87-02.93	■
2.0 i (N4A)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i (N4A)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i (N4I)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i (N4I)	01/91-	Gasolina	RWD	1993	85	115	01.87-02.93	■
2.0 i DOHC (N9E)		Gasolina	RWD	1998	85	115	12.91-02.93	■
2.0 i DOHC (N9E)		Gasolina	RWD	1998	85	115	12.91-02.93	■
2.0 4x4 (N9C)	01/91-	Gasolina	4WD	1998	88	120	02.90-02.93	■
2.0 4x4 (N9C)	01/91-	Gasolina	4WD	1998	88	120	02.90-02.93	■
2.0 i (N9C)	01/91-	Gasolina	RWD	1998	88	120	05.89-02.93	■
2.0 i (N9C)	01/91-	Gasolina	RWD	1998	88	120	05.89-02.93	■
2.0 4x4 (N9C)	01/91-	Gasolina	4WD	1998	92	125	05.89-02.93	■
2.0 4x4 (N9C)	01/91-	Gasolina	4WD	1998	92	125	05.89-02.93	■
2.0 i (N9C)	01/91-	Gasolina	RWD	1998	92	125	05.89-02.93	■
2.0 i (N9C)	01/91-	Gasolina	RWD	1998	92	125	05.89-02.93	■
1.8 TD (RFA)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFA)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFB)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFB)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFL)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■
1.8 TD (RFL)	01/91-	Diesel	RWD	1753	55	75	08.88-02.93	■