

1

LISTA DE APLICACIONES - BUYERS GUIDE

2.0 i 16V (RFY (XU10J4/Z))		Gasolina	FWD	1998	112	152	03.93-01.98
3.0 i 24V (XFZ (ES9J4))		Gasolina	FWD	2946	140	190	01.97-04.03
3.0 i 24V (XFZ (ES9J4))		Gasolina	FWD	2946	140	190	01.97-04.03
3.0 V6	-12/02	Gasolina	FWD	2946	140	190	01.98-04.03
3.0 V6	-12/02	Gasolina	FWD	2946	140	190	01.98-04.03
1.9 D (DJZ (XUD9A))		Diesel	FWD	1905	50	68	06.94-01.98
1.9 D (DJZ (XUD9A))		Diesel	FWD	1905	50	68	06.94-01.98
1.9 D (D9B (XUD9A/L))		Diesel	FWD	1905	51	69	06.94-01.98
1.9 D (D9B (XUD9A/L))		Diesel	FWD	1905	51	69	06.94-01.98
1.9 SD (DHW (XUD9SD))		Diesel	FWD	1905	55	75	02.96-04.03
1.9 SD (DHW (XUD9SD))		Diesel	FWD	1905	55	75	02.96-04.03
1.9 SD	-12/00	Diesel	FWD	1905	55	75	01.98-04.03
1.9 SD	-12/00	Diesel	FWD	1905	55	75	01.98-04.03
1.9 Turbo D (DHX (XUD9TF/BTF))		Diesel	FWD	1905	66	90	05.93-04.03
1.9 Turbo D (DHX (XUD9TF/BTF))		Diesel	FWD	1905	66	90	05.93-04.03
1.9 Turbo D (DHY (XUD9TE/Y))		Diesel	FWD	1905	66	90	05.93-04.03
1.9 Turbo D (DHY (XUD9TE/Y))		Diesel	FWD	1905	66	90	05.93-04.03
2.0 HDI 90 (RHY (DW10TD))		Diesel	FWD	1997	66	90	03.99-04.03
2.0 HDI 90 (RHY (DW10TD))		Diesel	FWD	1997	66	90	03.99-04.03
2.0 HDI 109 (RHZ (DW10ATED))		Diesel	FWD	1997	80	109	02.99-04.03
2.0 HDI 109 (RHZ (DW10ATED))		Diesel	FWD	1997	80	109	02.99-04.03
2.1 Turbo D 12V (P8C (XUD11BTE))		Diesel	FWD	2088	80	109	06.95-02.99
2.1 Turbo D 12V (P8C (XUD11BTE))		Diesel	FWD	2088	80	109	06.95-02.99
2.1 Turbo D 12V		Diesel	FWD	2088	80	109	01.98-02.99
2.1 Turbo D 12V		Diesel	FWD	2088	80	109	01.98-02.99

