


LISTA DE APLICACIONES - BUYERS GUIDE

30896-5610



Weight: 14.060



1-Ref. 610289 E

30896-5610



Bendix

138.9x64.1x19

Ø254x24x43

WVA

21470

MAKE

FORD



Trac.

CC

Kw

CV



Front / Rear

FORD

TRANSIT III (E_) 01.91-09.94

Bus (Minibus-M2-Segment)

Model	Year	Engine	Trac.	CC	Kw	CV	Period	Front / Rear
2.0 (NBA)		Gasolina	RWD	1993	66	90	09.91-09.94	■
2.0 (NBA)		Gasolina	RWD	1993	66	90	09.91-09.94	■
2.0 i (EBL, EDL, EGL, ESS, EUS) (NCA)		Gasolina	RWD	1994	72	98	09.91-07.94	■
2.0 i (EBL, EDL, EGL, ESS, EUS) (NCA)		Gasolina	RWD	1994	72	98	09.91-07.94	■
2.0 (EBL, EBS, ECL, EDS, EDL, EGL, ESS, ESL, EUS) (NSF)		Gasolina	RWD	1998	84	114	08.94-03.00	■
2.0 (EBL, EBS, ECL, EDS, EDL, EGL, ESS, ESL, EUS) (NSF)		Gasolina	RWD	1998	84	114	08.94-03.00	■
2.0 (EBL, EBS, ECL, EDS, EDL, EGL, ESS, ESL, EUS) (NSG)		Gasolina	RWD	1998	84	114	08.94-03.00	■
2.0 (EBL, EBS, ECL, EDS, EDL, EGL, ESS, ESL, EUS) (NSG)		Gasolina	RWD	1998	84	114	08.94-03.00	■
2.0 (EBL, EBS, ECL, EDS, EDL, EGL, ESS, ESL, EUS) (NSH)		Gasolina	RWD	1998	84	114	08.94-03.00	■
2.0 (EBL, EBS, ECL, EDS, EDL, EGL, ESS, ESL, EUS) (NSH)		Gasolina	RWD	1998	84	114	08.94-03.00	■
2.9 i (BRT)		Gasolina	RWD	2935	107	145	01.91-09.94	■
2.9 i (BRT)		Gasolina	RWD	2935	107	145	01.91-09.94	■
2.0 CNG (NSH)		Gasol./Gas (CNG)	RWD	1998	84	114	06.94-03.00	■
2.0 CNG (NSH)		Gasol./Gas (CNG)	RWD	1998	84	114	06.94-03.00	■
2.5 DI (EBL, EDS, ESL, ESS, EUS) (4FA)	01/95-	Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EBL, EDS, ESL, ESS, EUS) (4FA)	01/95-	Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EBL, EDS, ESL, ESS, EUS) (4FB)	01/95-	Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EBL, EDS, ESL, ESS, EUS) (4FB)	01/95-	Diesel	RWD	2496	51	69	08.94-03.00	■

LISTA DE APLICACIONES - BUYERS GUIDE

2.5 DI (EBL, EDS, ESL, ESS, EUS) (4FC)	01/95-	Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EBL, EDS, ESL, ESS, EUS) (4FC)	01/95-	Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EBL, EDS, ESL, ESS, EUS) (4FD)	01/95-	Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EBL, EDS, ESL, ESS, EUS) (4FD)	01/95-	Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EBS, EDS, EDL, ESS, EUS) (4BC)		Diesel	RWD	2496	51	70	08.91-07.94	■
2.5 DI (EBS, EDS, EDL, ESS, EUS) (4BC)		Diesel	RWD	2496	51	70	08.91-07.94	■
2.5 DI (EBS, EDS, EDL, ESS, EUS) (4CC)		Diesel	RWD	2496	51	70	08.91-07.94	■
2.5 DI (EBS, EDS, EDL, ESS, EUS) (4CC)		Diesel	RWD	2496	51	70	08.91-07.94	■
2.5 DI (EBS, EDS, EDL, ESS, EUS) (4FA)		Diesel	RWD	2496	51	70	08.91-07.94	■
2.5 DI (EBS, EDS, EDL, ESS, EUS) (4FA)		Diesel	RWD	2496	51	70	08.91-07.94	■
2.5 TD (EB_, ED_, ES_) (4HA)		Diesel	RWD	2496	55	75	08.94-06.00	■
2.5 TD (EB_, ED_, ES_) (4HA)		Diesel	RWD	2496	55	75	08.94-06.00	■
2.5 TD (EB_, ED_, ES_) (4HD)		Diesel	RWD	2496	55	75	08.94-06.00	■
2.5 TD (EB_, ED_, ES_) (4HD)		Diesel	RWD	2496	55	75	08.94-06.00	■
2.5 DI (EBL, ECL, EDS, EDL) (4HB)		Diesel	RWD	2496	56	76	07.94-03.00	■
2.5 DI (EBL, ECL, EDS, EDL) (4HB)		Diesel	RWD	2496	56	76	07.94-03.00	■
2.5 DI (EBL, ECL, EDS, EDL) (4HC)		Diesel	RWD	2496	56	76	07.94-03.00	■
2.5 DI (EBL, ECL, EDS, EDL) (4HC)		Diesel	RWD	2496	56	76	07.94-03.00	■
2.5 DI (EBS, EDS, EGL, ESS, EUS) (4DA)		Diesel	RWD	2496	59	80	09.91-07.94	■
2.5 DI (EBS, EDS, EGL, ESS, EUS) (4DA)		Diesel	RWD	2496	59	80	09.91-07.94	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GA)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GA)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GB)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GB)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GC)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GC)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GD)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GD)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GE)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GE)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GF)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBL, EDL, EDS, EGL, ESL, ESS, EUS) (4GF)		Diesel	RWD	2496	63	85	01.95-03.00	■
2.5 TD (EBS, EBL, ECL, EDS, EDL, ESS, EUS) (4GA)		Diesel	RWD	2496	63	85	10.92-07.94	■
2.5 TD (EBS, EBL, ECL, EDS, EDL, ESS, EUS) (4GA)		Diesel	RWD	2496	63	85	10.92-07.94	■
2.5 TD (ECL, EDL, EDS, ESL, ESS, EUS) (4EB)		Diesel	RWD	2496	74	100	07.94-03.00	■
2.5 TD (ECL, EDL, EDS, ESL, ESS, EUS) (4EB)		Diesel	RWD	2496	74	100	07.94-03.00	■
2.5 TD (ECL, EDL, EDS, ESL, ESS, EUS) (4EC)		Diesel	RWD	2496	74	100	07.94-03.00	■
2.5 TD (ECL, EDL, EDS, ESL, ESS, EUS) (4EC)		Diesel	RWD	2496	74	100	07.94-03.00	■
2.5 TD (ECL, EDS, EDL, EGL, ESS, EUS) (4EA)		Diesel	RWD	2496	74	100	09.91-07.94	■
2.5 TD (ECL, EDS, EDL, EGL, ESS, EUS) (4EA)		Diesel	RWD	2496	74	100	09.91-07.94	■
2.5 DI (EBL, EDL, EDS, ESL, ESS) (4ED)		Diesel	RWD	2496	85	116	08.97-03.00	■
2.5 DI (EBL, EDL, EDS, ESL, ESS) (4ED)		Diesel	RWD	2496	85	116	08.97-03.00	■

LISTA DE APLICACIONES - BUYERS GUIDE

TRANSIT III (E _) 04.91-08.94					Platform/Chassis (LCVs-N1 Segment)			
2.0 (EME/L/S, ENE/L/S) (NCA)		Gasolina	RWD	1994	72	98	09.91-08.94	■
2.0 (EME/L/S, ENE/L/S) (NCA)		Gasolina	RWD	1994	72	98	09.91-08.94	■
2.0 (EME/L/S, ENE/L/S) (NSF)		Gasolina	RWD	1998	84	114	08.94-03.00	■
2.0 (EME/L/S, ENE/L/S) (NSF)		Gasolina	RWD	1998	84	114	08.94-03.00	■
2.0 (EME/L/S, ENE/L/S) (NSG)		Gasolina	RWD	1998	84	114	08.94-03.00	■
2.0 (EME/L/S, ENE/L/S) (NSG)		Gasolina	RWD	1998	84	114	08.94-03.00	■
2.5 DI (EML/S, ENL/S) (4BC)		Diesel	RWD	2496	51	69	09.91-08.94	■
2.5 DI (EML/S, ENL/S) (4BC)		Diesel	RWD	2496	51	69	09.91-08.94	■
2.5 DI (EML/S, ENL/S) (4CC)		Diesel	RWD	2496	51	69	09.91-08.94	■
2.5 DI (EML/S, ENL/S) (4CC)		Diesel	RWD	2496	51	69	09.91-08.94	■
2.5 DI (EML/S, ENL/S) (4FA)		Diesel	RWD	2496	51	69	09.91-08.94	■
2.5 DI (EML/S, ENL/S) (4FA)		Diesel	RWD	2496	51	69	09.91-08.94	■
2.5 DI (EML/S, ENL/S) (4FA)		Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EML/S, ENL/S) (4FA)		Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EML/S, ENL/S) (4FB)		Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EML/S, ENL/S) (4FB)		Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EML/S, ENL/S) (4FC)		Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EML/S, ENL/S) (4FC)		Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EML/S, ENL/S) (4FD)		Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 DI (EML/S, ENL/S) (4FD)		Diesel	RWD	2496	51	69	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S)		Diesel	RWD	2496	55	75	10.98-07.00	■
2.5 TD (EME/L/S, ENE/L/S)		Diesel	RWD	2496	55	75	10.98-07.00	■
2.5 DI (EME/L/S, ENE/L/S) (4HB)		Diesel	RWD	2496	56	76	08.94-03.00	■
2.5 DI (EME/L/S, ENE/L/S) (4HB)		Diesel	RWD	2496	56	76	08.94-03.00	■
2.5 DI (EME/L/S, ENE/L/S) (4HC)		Diesel	RWD	2496	56	76	08.94-03.00	■
2.5 DI (EME/L/S, ENE/L/S) (4HC)		Diesel	RWD	2496	56	76	08.94-03.00	■
2.5 DI (EME/L/S, ENE/L/S) (4DA)		Diesel	RWD	2496	59	80	09.91-08.94	■
2.5 DI (EME/L/S, ENE/L/S) (4DA)		Diesel	RWD	2496	59	80	09.91-08.94	■
2.5 TD (EME/L/S, ENE/L/S) (4GA)		Diesel	RWD	2496	63	85	11.92-08.94	■
2.5 TD (EME/L/S, ENE/L/S) (4GA)		Diesel	RWD	2496	63	85	11.92-08.94	■
2.5 TD (EME/L/S, ENE/L/S) (4GA)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GA)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GB)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GB)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GC)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GC)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GD)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GD)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GE)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GE)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GF)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4GF)	01/95-	Diesel	RWD	2496	63	85	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L) (4EA)		Diesel	RWD	2496	74	100	09.91-08.94	■
2.5 TD (EME/L/S, ENE/L) (4EA)		Diesel	RWD	2496	74	100	09.91-08.94	■
2.5 TD (EME/L/S, ENE/L/S) (4EB)		Diesel	RWD	2496	74	101	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4EB)		Diesel	RWD	2496	74	101	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4EC)		Diesel	RWD	2496	74	101	08.94-03.00	■
2.5 TD (EME/L/S, ENE/L/S) (4EC)		Diesel	RWD	2496	74	101	08.94-03.00	■
2.5 DI (EML, ENE/L) (4ED)		Diesel	RWD	2496	85	116	05.99-03.00	■
2.5 DI (EML, ENE/L) (4ED)		Diesel	RWD	2496	85	116	05.99-03.00	■

LISTA DE APLICACIONES - BUYERS GUIDE

TRANSIT III (E_) 05.91-06.94					Van (LCVs-N1 Segment)			
2.0 (NBA)		Gasolina	RWD	1993	66	90	09.91-06.94	■
2.0 (NBA)		Gasolina	RWD	1993	66	90	09.91-06.94	■
2.0 i (EAL, EAS) (NCA)		Gasolina	RWD	1994	72	98	09.91-06.94	■
2.0 i (EAL, EAS) (NCA)		Gasolina	RWD	1994	72	98	09.91-06.94	■
2.0 (EAL, EAS) (NSF)		Gasolina	RWD	1998	84	114	06.94-03.00	■
2.0 (EAL, EAS) (NSF)		Gasolina	RWD	1998	84	114	06.94-03.00	■
2.0 (EAL, EAS) (NSG)		Gasolina	RWD	1998	84	114	06.94-03.00	■
2.0 (EAL, EAS) (NSG)		Gasolina	RWD	1998	84	114	06.94-03.00	■
2.0 (EAL, EAS) (NSH)		Gasolina	RWD	1998	84	114	06.94-03.00	■
2.0 (EAL, EAS) (NSH)		Gasolina	RWD	1998	84	114	06.94-03.00	■
2.5 DI (EAL, EAS) (4BC)		Diesel	RWD	2496	51	70	05.91-06.94	■
2.5 DI (EAL, EAS) (4BC)		Diesel	RWD	2496	51	70	05.91-06.94	■
2.5 DI (EAL, EAS) (4CC)		Diesel	RWD	2496	51	70	05.91-06.94	■
2.5 DI (EAL, EAS) (4CC)		Diesel	RWD	2496	51	70	05.91-06.94	■
2.5 DI (EAL, EAS) (4FA)		Diesel	RWD	2496	51	70	05.91-06.94	■
2.5 DI (EAL, EAS) (4FA)		Diesel	RWD	2496	51	70	05.91-06.94	■
2.5 DI (EAL, EAS) (4FA)		Diesel	RWD	2496	51	69	06.94-03.00	■
2.5 DI (EAL, EAS) (4FA)		Diesel	RWD	2496	51	69	06.94-03.00	■
2.5 DI (EAL, EAS) (4FB)		Diesel	RWD	2496	51	69	06.94-03.00	■
2.5 DI (EAL, EAS) (4FB)		Diesel	RWD	2496	51	69	06.94-03.00	■
2.5 DI (EAL, EAS) (4FC)		Diesel	RWD	2496	51	69	06.94-03.00	■
2.5 DI (EAL, EAS) (4FC)		Diesel	RWD	2496	51	69	06.94-03.00	■
2.5 DI (EAL, EAS) (4FD)		Diesel	RWD	2496	51	69	06.94-03.00	■
2.5 DI (EAL, EAS) (4FD)		Diesel	RWD	2496	51	69	06.94-03.00	■
2.5 TD (EAS) (4HA)		Diesel	RWD	2496	55	75	06.94-03.00	■
2.5 TD (EAS) (4HA)		Diesel	RWD	2496	55	75	06.94-03.00	■
2.5 TD (EAS) (4HD)		Diesel	RWD	2496	55	75	06.94-03.00	■
2.5 TD (EAS) (4HD)		Diesel	RWD	2496	55	75	06.94-03.00	■
2.5 DI (EAL, EAS) (4HB)		Diesel	RWD	2496	56	76	06.94-03.00	■
2.5 DI (EAL, EAS) (4HB)		Diesel	RWD	2496	56	76	06.94-03.00	■
2.5 DI (EAL, EAS) (4HC)		Diesel	RWD	2496	56	76	06.94-03.00	■
2.5 DI (EAL, EAS) (4HC)		Diesel	RWD	2496	56	76	06.94-03.00	■
2.5 DI (EAS, EAL) (4DA)		Diesel	RWD	2496	59	80	05.91-06.94	■
2.5 DI (EAS, EAL) (4DA)		Diesel	RWD	2496	59	80	05.91-06.94	■
2.5 DI (EAL, EAS) (4GA)		Diesel	RWD	2496	63	85	10.92-06.94	■
2.5 DI (EAL, EAS) (4GA)		Diesel	RWD	2496	63	85	10.92-06.94	■
2.5 TD (EAL, EAS) (4GA)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GA)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GB)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GB)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GC)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GC)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GD)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GD)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GE)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GE)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GF)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAL, EAS) (4GF)	01/95-	Diesel	RWD	2496	63	85	06.94-03.00	■
2.5 TD (EAS, EAL) (4EA)		Diesel	RWD	2496	74	101	05.91-06.94	■
2.5 TD (EAS, EAL) (4EA)		Diesel	RWD	2496	74	101	05.91-06.94	■

LISTA DE APLICACIONES - BUYERS GUIDE

2.5 TDI (EAL, EAS) (4EB)	Diesel	RWD	2496	74	101	06.94-03.00	■
2.5 TDI (EAL, EAS) (4EB)	Diesel	RWD	2496	74	101	06.94-03.00	■
2.5 TDI (EAL, EAS) (4EC)	Diesel	RWD	2496	74	101	06.94-03.00	■
2.5 TDI (EAL, EAS) (4EC)	Diesel	RWD	2496	74	101	06.94-03.00	■
2.5 DI (EAL, EAS) (4ED)	Diesel	RWD	2496	85	116	05.99-03.00	■
2.5 DI (EAL, EAS) (4ED)	Diesel	RWD	2496	85	116	05.99-03.00	■