


LISTA DE APLICACIONES - BUYERS GUIDE

30917-6784



Weight: 13.209



30917-6784



Ate - Teves

155.2x58.6x18

Ø260x24x47

WVA

23071

MAKE

FORD



Trac.

CC

Kw

CV



Front / Rear

FORD

COUGAR (EC_) 08.98-12.01

Coupe (Sports car-S Segment)

2.0 16V (EDBA)	01/99-	Gasolina	FWD	1988	96	131	08.98-12.01	■
2.0 16V (EDBA)	01/99-	Gasolina	FWD	1988	96	131	08.98-12.01	■
2.0 16V (EDBB)	01/99-	Gasolina	FWD	1988	96	131	08.98-12.01	■
2.0 16V (EDBB)	01/99-	Gasolina	FWD	1988	96	131	08.98-12.01	■
2.0 16V (EDBC)	01/99-	Gasolina	FWD	1988	96	131	08.98-12.01	■
2.0 16V (EDBC)	01/99-	Gasolina	FWD	1988	96	131	08.98-12.01	■
2.0 16V (EDBD)	01/99-	Gasolina	FWD	1988	96	131	08.98-12.01	■
2.0 16V (EDBD)	01/99-	Gasolina	FWD	1988	96	131	08.98-12.01	■

MONDEO (GBP) 02.93-08.96

Hatchback (Large family car-D Segment)

1.6 i 16V (L1J)		Gasolina	FWD	1597	65	88	07.94-08.96	■
1.6 i 16V (L1J)		Gasolina	FWD	1597	65	88	07.94-08.96	■
1.6 i 16V (L1F)		Gasolina	FWD	1597	66	90	02.93-08.96	■
1.6 i 16V (L1F)		Gasolina	FWD	1597	66	90	02.93-08.96	■
1.8 i 16V (RKB)		Gasolina	FWD	1796	82	112	07.94-08.96	■
1.8 i 16V (RKB)		Gasolina	FWD	1796	82	112	07.94-08.96	■
1.8 i 16V (RKA)		Gasolina	FWD	1796	85	115	02.93-08.96	■
1.8 i 16V (RKA)		Gasolina	FWD	1796	85	115	02.93-08.96	■
2.0 i 16V (NGA)		Gasolina	FWD	1988	97	132	12.94-08.96	■
2.0 i 16V (NGA)		Gasolina	FWD	1988	97	132	12.94-08.96	■
2.0 i 16V (NGA)		Gasolina	FWD	1988	100	136	02.93-08.96	■
2.0 i 16V (NGA)		Gasolina	FWD	1988	100	136	02.93-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	65	88	06.93-08.96	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.8 TD (RFM)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	66	90	10.95-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	66	90	10.95-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	10.95-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	10.95-08.96	■
MONDEO (GBP) 01.93-08.96					Saloon (Large family car-D Segment)			
1.6 i 16V (L1J)		Gasolina	FWD	1597	65	88	07.94-08.96	■
1.6 i 16V (L1J)		Gasolina	FWD	1597	65	88	07.94-08.96	■
1.6 i 16V (L1F)		Gasolina	FWD	1597	66	90	02.93-08.96	■
1.6 i 16V (L1F)		Gasolina	FWD	1597	66	90	02.93-08.96	■
1.8 i 16V (RKB)		Gasolina	FWD	1796	82	112	01.94-08.96	■
1.8 i 16V (RKB)		Gasolina	FWD	1796	82	112	01.94-08.96	■
1.8 i 16V (RKA)		Gasolina	FWD	1796	85	115	02.93-08.96	■
1.8 i 16V (RKA)		Gasolina	FWD	1796	85	115	02.93-08.96	■
2.0 i 16V (NGA)		Gasolina	FWD	1988	100	136	02.93-08.96	■
2.0 i 16V (NGA)		Gasolina	FWD	1988	100	136	02.93-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	66	90	10.95-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	66	90	10.95-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	10.95-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	10.95-08.96	■
MONDEO II (BAP) 08.96-09.00					Hatchback (Large family car-D Segment)			
1.6 i (L1J)		Gasolina	FWD	1597	66	90	08.96-09.00	■
1.6 i (L1J)		Gasolina	FWD	1597	66	90	08.96-09.00	■
1.6 i 16V (L1L)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1L)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1N)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1N)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1Q)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1Q)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.8 i (RKB)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKB)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKF)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKF)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKH)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKH)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKJ)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKJ)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKK)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKK)		Gasolina	FWD	1796	85	115	08.96-09.00	■
2.0 i (NGA)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGA)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGB)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGB)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGC)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■

LISTA DE APLICACIONES - BUYERS GUIDE

2.0 i (NGC)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGD)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGD)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	08.96-09.00	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	08.96-09.00	■
MONDEO II (BFP) 08.96-09.00					Saloon (Large family car-D Segment)			
1.6 i (L1J)		Gasolina	FWD	1597	66	90	08.96-09.00	■
1.6 i (L1J)		Gasolina	FWD	1597	66	90	08.96-09.00	■
1.6 i 16V (L1L)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1L)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1N)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1N)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1Q)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1Q)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.8 i (RKB)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKB)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKF)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKF)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKH)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKH)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKJ)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKJ)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKK)		Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKK)		Gasolina	FWD	1796	85	115	08.96-09.00	■
2.0 i (NGA)	01/99-	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGA)	01/99-	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGB)	01/99-	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGB)	01/99-	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGC)	01/99-	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGC)	01/99-	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGD)	01/99-	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGD)	01/99-	Gasolina	FWD	1988	96	131	08.96-09.00	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	08.96-09.00	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	08.96-09.00	■
MONDEO II Turnier (BNP) 08.96-09.00					Estate (Large family car-D Segment)			
1.6 i (L1J)		Gasolina	FWD	1597	66	90	08.96-09.00	■
1.6 i (L1J)		Gasolina	FWD	1597	66	90	08.96-09.00	■
1.6 i 16V (L1L)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1L)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1N)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1N)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1Q)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.6 i 16V (L1Q)		Gasolina	FWD	1597	70	95	05.98-09.00	■
1.8 i (RKA)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKA)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKB)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKB)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKF)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKF)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKH)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.8 i (RKH)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKJ)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKJ)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKK)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
1.8 i (RKK)	-12/99	Gasolina	FWD	1796	85	115	08.96-09.00	■
2.0 i (NGA)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGA)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGB)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGB)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGC)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGC)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGD)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
2.0 i (NGD)	-12/99	Gasolina	FWD	1988	96	131	08.96-09.00	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	08.96-09.00	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	08.96-09.00	■
MONDEO Turnier (BNP) 01.93-08.96					Estate (Large family car-D Segment)			
1.6 i 16V (L1J)		Gasolina	FWD	1597	65	88	07.94-08.96	■
1.6 i 16V (L1J)		Gasolina	FWD	1597	65	88	07.94-08.96	■
1.6 i 16V (L1F)		Gasolina	FWD	1597	66	90	04.93-08.96	■
1.6 i 16V (L1F)		Gasolina	FWD	1597	66	90	04.93-08.96	■
1.8 i 16V (RKB)		Gasolina	FWD	1796	82	112	07.94-08.96	■
1.8 i 16V (RKB)		Gasolina	FWD	1796	82	112	07.94-08.96	■
1.8 i 16V (RKA)		Gasolina	FWD	1796	85	115	04.93-08.96	■
1.8 i 16V (RKA)		Gasolina	FWD	1796	85	115	04.93-08.96	■
2.0 i 16V (NGA)	01/94-	Gasolina	FWD	1988	97	132	01.93-08.96	■
2.0 i 16V (NGA)	01/94-	Gasolina	FWD	1988	97	132	01.93-08.96	■
2.0 i 16V 4x4 (NGA)		Gasolina	4WD	1988	97	132	12.94-08.96	■
2.0 i 16V 4x4 (NGA)		Gasolina	4WD	1988	97	132	12.94-08.96	■
2.0 i 16V (NGA)		Gasolina	FWD	1988	100	136	04.93-08.96	■
2.0 i 16V (NGA)		Gasolina	FWD	1988	100	136	04.93-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	65	88	06.93-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	66	90	11.95-08.96	■
1.8 TD (RFM)		Diesel	FWD	1753	66	90	11.95-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	11.95-08.96	■
1.8 TD (RFN)		Diesel	FWD	1753	66	90	11.95-08.96	■
SCORPIO II (GFR, GGR) 10.94-08.98					Saloon (Executive car-E Segment)			
2.0 i (NSD)		Gasolina	RWD	1998	85	115	10.94-08.98	■
2.0 i (NSD)		Gasolina	RWD	1998	85	115	10.94-08.98	■
2.0 i 16V (N3A)		Gasolina	RWD	1998	100	136	10.94-08.98	■
2.0 i 16V (N3A)		Gasolina	RWD	1998	100	136	10.94-08.98	■
2.3 i 16V (Y5A)		Gasolina	RWD	2295	108	147	06.96-08.98	■
2.3 i 16V (Y5A)		Gasolina	RWD	2295	108	147	06.96-08.98	■
2.9 i (BRG)		Gasolina	RWD	2933	110	150	02.95-08.98	■
2.9 i (BRG)		Gasolina	RWD	2933	110	150	02.95-08.98	■
2.5 TD (VM)		Diesel	RWD	2499	92	125	09.96-08.98	■
2.5 TD (VM)		Diesel	RWD	2499	92	125	09.96-08.98	■
2.5 TD (SCC)		Diesel	RWD	2500	85	115	10.94-08.98	■
2.5 TD (SCC)		Diesel	RWD	2500	85	115	10.94-08.98	■

LISTA DE APLICACIONES - BUYERS GUIDE

SCORPIO II Turnier (GNR, GGR) 10.94-08.98					Estate (Executive car-E Segment)			
2.0 i (NSD)	Gasolina	RWD	1998	85	115	10.94-08.98	■	
2.0 i (NSD)	Gasolina	RWD	1998	85	115	10.94-08.98	■	
2.0 i 16V (N3A)	Gasolina	RWD	1998	100	136	10.94-08.98	■	
2.0 i 16V (N3A)	Gasolina	RWD	1998	100	136	10.94-08.98	■	
2.3 i 16V (Y5A)	Gasolina	RWD	2295	108	147	06.96-08.98	■	
2.3 i 16V (Y5A)	Gasolina	RWD	2295	108	147	06.96-08.98	■	
2.9 i (BRG)	Gasolina	RWD	2933	110	150	02.95-08.98	■	
2.9 i (BRG)	Gasolina	RWD	2933	110	150	02.95-08.98	■	
2.5 TD (VM)	Diesel	RWD	2499	92	125	09.96-08.98	■	
2.5 TD (VM)	Diesel	RWD	2499	92	125	09.96-08.98	■	
2.5 TD (SCC)	Diesel	RWD	2500	85	115	10.94-08.98	■	
2.5 TD (SCC)	Diesel	RWD	2500	85	115	10.94-08.98	■	