

LISTA DE APLICACIONES - BUYERS GUIDE

2.0 DI (F_E_, F_F_) (ABFA)	Diesel	FWD	1998	74	100	08.00-05.06	■
2.0 TDCi (F_E_, F_F_) (FIFA)	Diesel	FWD	1998	92	125	08.02-05.06	■
2.0 TDCi (F_E_, F_F_) (FIFA)	Diesel	FWD	1998	92	125	08.02-05.06	■
2.4 TDdi	Diesel	RWD	2402	88	120	08.00-08.03	■
2.4 TDdi	Diesel	RWD	2402	88	120	08.00-08.03	■
TRANSIT IV (FA_ _) 01.00-05.06				Van (LCVs-N1 Segment)			
2.3 (E5FC)	Gasolina	RWD	2295	105	143	03.01-03.06	■
2.3 (E5FC)	Gasolina	RWD	2295	105	143	03.01-03.06	■
2.3	Gasolina	RWD	2295	107	145	03.01-03.06	■
2.3	Gasolina	RWD	2295	107	145	03.01-03.06	■
2.0 DI (FAE_, FAF_, FAG_) (D3FA)	Diesel	FWD	1998	55	75	08.00-05.06	■
2.0 DI (FAE_, FAF_, FAG_) (D3FA)	Diesel	FWD	1998	55	75	08.00-05.06	■
2.0 DI (FAE_, FAF_, FAG_) (F3FA)	Diesel	FWD	1998	63	86	08.00-05.06	■
2.0 DI (FAE_, FAF_, FAG_) (F3FA)	Diesel	FWD	1998	63	86	08.00-05.06	■
2.0 DI (FAE_, FAF_, FAG_) (ABFA)	Diesel	FWD	1998	74	100	08.00-05.06	■
2.0 DI (FAE_, FAF_, FAG_) (ABFA)	Diesel	FWD	1998	74	100	08.00-05.06	■
2.0 TDCi (FIFA)	Diesel	FWD	1998	92	125	08.02-05.06	■
2.0 TDCi (FIFA)	Diesel	FWD	1998	92	125	08.02-05.06	■
2.4 TD (F4FA)	Diesel	FWD	2402	55	75	08.00-08.03	■
2.4 TD (F4FA)	Diesel	FWD	2402	55	75	08.00-08.03	■
2.4 TDdi	Diesel	RWD	2402	88	120	08.00-08.03	■
2.4 TDdi	Diesel	RWD	2402	88	120	08.00-08.03	■
2.4 TDE (DOFA)	Diesel	RWD	2402	92	125	07.01-05.06	■
2.4 TDE (DOFA)	Diesel	RWD	2402	92	125	07.01-05.06	■