

LISTA DE APLICACIONES - BUYERS GUIDE

78CV0051-1



Qty: 998

Weight: 15.000

O.E.M.	MAKE
1962302	DAF
81508030024	MAN
81508030026	MAN
MBR5012	MERITOR



78CV0051-1



Ø330x34x104

MAKE
MAN



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

MAN

FOCL

8.110	Diesel	4580	81	110	05.95-03.01	■
8.110	Diesel	4580	83	113	05.95-03.01	■
8.140	Diesel	4580	103	140	07.99-03.01	■
8.140	Diesel	4580	104	141	05.95-03.01	■
8.150	Diesel	4580	110	150	07.99-03.01	■
8.160	Diesel	4580	118	160	05.95-03.01	■
8.170	Diesel	4580	125	170	07.99-03.01	■
8.180	Diesel	4580	132	179	07.99-03.01	■
10.245	Diesel	6871	180	245	05.99-02.07	■
8.245	Diesel	6871	180	245	05.99-02.07	■
10.255	Diesel	6871	188	256	03.95-08.06	■
8.255	Diesel	6871	188	256	03.95-10.97	■
10.260	Diesel	6871	191	260	03.95-08.06	■
8.260	Diesel	6871	191	260	03.95-03.01	■
10.265	Diesel	6871	196	266	04.98-10.01	■
8.265	Diesel	6871	196	266	04.98-10.01	■
10.280	Diesel	6871	206	280	04.98-02.07	■
8.280	Diesel	6871	206	280	04.98-02.07	■

L2000 06.93-

Bus

10.150 FOC (D 0824 LFO)	Diesel	4580	114	155	02.95-01.96	■
8.150 FOC,8.150 FOCL (D 0824 LFO)	Diesel	4580	114	155	02.95-	■
10.220 FOC,10.220 FOCL (D 0826 LFL03)	Diesel	6871	162	220	02.95-	■
8.220 FOC,8.220 FOCL (D 0826 LFL03)	Diesel	6871	162	220	04.95-	■

LISTA DE APLICACIONES - BUYERS GUIDE

L2000 06.93-					Dump Truck			
6.103	Diesel		4580	75	102	06.93-08.06	■	
7.103	Diesel		4580	75	102	06.93-08.06	■	
8.103 LK (D 0824 FL 01)	Diesel		4580	75	102	10.93-06.96	■	
6.113	Diesel		4580	81	110	06.93-08.06	■	
7.113	Diesel		4580	81	110	06.93-08.06	■	
7.113	Diesel		4580	81	110	06.00-10.01	■	
8.113 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 04)	Diesel		4580	81	110	08.95-	■	
8.113 LK, L-KI, LRK, LR-KI, LRK-L, LK-L	Diesel		4580	81	110	08.95-	■	
9.113	Diesel		4580	81	110	06.00-10.01	■	
6.113	Diesel		4580	83	113	01.97-08.06	■	
7.113	Diesel		4580	83	113	01.97-08.06	■	
7.113	Diesel		4580	83	113	06.00-10.01	■	
8.113	Diesel		4580	83	113	01.97-08.06	■	
8.113	Diesel		4580	83	113	01.97-04.06	■	
9.113	Diesel		4580	83	113	06.00-10.01	■	
10.145 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE140C) (D 0834 LFL 02)	Diesel		4580	103	140	09.00-	■	
6.143	Diesel		4580	103	140	07.99-08.06	■	
6.145	Diesel		4580	103	140	06.00-01.04	■	
7.143	Diesel		4580	103	140	07.99-08.06	■	
7.145	Diesel		4580	103	140	06.00-01.04	■	
8.145 LK, LRK, L-KI, LRK-L, LK-L, LR-KILK (LE140C) (D 0834 LFL 02)	Diesel		4580	103	140	09.00-	■	
9.145 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE140C) (D 0834 LFL 02)	Diesel		4580	103	140	09.00-	■	
10.145	Diesel		4580	104	141	06.93-04.06	■	
6.143	Diesel		4580	104	141	06.93-08.06	■	
6.145	Diesel		4580	104	141	06.00-10.01	■	
7.143	Diesel		4580	104	141	06.93-08.06	■	
7.145	Diesel		4580	104	141	06.00-10.01	■	
8.145	Diesel		4580	104	141	06.93-08.06	■	
8.145	Diesel		4580	104	141	06.93-04.06	■	
9.145	Diesel		4580	104	141	06.93-08.06	■	
9.163 LK (D 0824 LFL 07)	Diesel		4580	104	141	08.95-03.97	■	
10.153	Diesel		4580	110	150	07.99-04.06	■	
10.155	Diesel		4580	110	150	07.99-04.06	■	
6.153	Diesel		4580	110	150	07.99-08.06	■	
7.153	Diesel		4580	110	150	07.99-08.06	■	
7.153	Diesel		4580	110	150	06.00-01.04	■	
8.153	Diesel		4580	110	150	07.99-08.06	■	
8.153	Diesel		4580	110	150	07.99-04.06	■	
8.155	Diesel		4580	110	150	07.99-08.06	■	
8.155	Diesel		4580	110	150	07.99-04.06	■	
9.153	Diesel		4580	110	150	07.99-08.06	■	
9.155	Diesel		4580	110	150	07.99-08.06	■	
10.153 LK (D 0824 LFL 01)	Diesel		4580	114	155	10.93-06.96	■	
10.153 LK (D 0824 LFL 05)	Diesel		4580	114	155	10.93-06.96	■	
10.155 LK, L-KI, LRK, LR-KI, LK-L	Diesel		4580	114	155	02.04-	■	
10.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 02)	Diesel		4580	114	155	05.94-	■	
10.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 06)	Diesel		4580	114	155	05.94-	■	

LISTA DE APLICACIONES - BUYERS GUIDE

10.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 09)	Diesel	4580	114	155	05.94-	■
6.153	Diesel	4580	114	155	06.93-08.06	■
6.163	Diesel	4580	114	155	04.97-08.06	■
7.153	Diesel	4580	114	155	06.93-08.06	■
7.153	Diesel	4580	114	155	06.00-10.01	■
7.163	Diesel	4580	114	155	04.97-08.06	■
8.153 LK (D 0824 LFL 01)	Diesel	4580	114	155	10.93-07.97	■
8.153 LK (D 0824 LFL 05)	Diesel	4580	114	155	10.93-07.97	■
8.155 LK, L-KI, LR-KI, LRK-L, LK-L	Diesel	4580	114	155	02.04-	■
8.155 LK, LRK	Diesel	4580	114	155	02.04-	■
8.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 02)	Diesel	4580	114	155	05.94-	■
8.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 06)	Diesel	4580	114	155	05.94-	■
8.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 09)	Diesel	4580	114	155	05.94-	■
8.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L	Diesel	4580	114	155	05.94-	■
9.153 LK (D 0824 LFL 01)	Diesel	4580	114	155	10.93-06.96	■
9.153 LK (D 0824 LFL 05)	Diesel	4580	114	155	10.93-06.96	■
9.155 LK, L-KI, LRK, LR-KI, LRK-L, LK-L	Diesel	4580	114	155	02.04-	■
9.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 02)	Diesel	4580	114	155	05.94-	■
9.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 06)	Diesel	4580	114	155	05.94-	■
9.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 09)	Diesel	4580	114	155	05.94-	■
6.163	Diesel	4580	118	160	06.93-08.06	■
7.163	Diesel	4580	118	160	06.93-08.06	■
7.163	Diesel	4580	118	160	06.00-10.01	■
10.174	Diesel	4580	125	170	06.00-01.04	■
6.174	Diesel	4580	125	170	07.99-08.06	■
7.174	Diesel	4580	125	170	07.99-08.06	■
7.174	Diesel	4580	125	170	06.00-01.04	■
8.174	Diesel	4580	125	170	06.00-01.04	■
9.174	Diesel	4580	125	170	06.00-01.04	■
10.185 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE180C) (D 0834 LFL 03)	Diesel	4580	132	180	09.00-	■
6.185	Diesel	4580	132	179	06.00-01.04	■
7.185	Diesel	4580	132	179	06.00-01.04	■
8.185 LK, L-KI, LRK, LR-KI LRK-L, LK-L (LE180C) (D 0834 LFL 03)	Diesel	4580	132	180	09.00-	■
9.185 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE180C) (D 0834 LFL 03)	Diesel	4580	132	180	09.00-	■
10.223 LK (D 0826 LFL02)	Diesel	6871	162	220	10.93-06.96	■
10.223 LK (D 0826 LFL06)	Diesel	6871	162	220	10.93-06.96	■
10.224 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0826 LFL03)	Diesel	6871	162	220	05.94-	■
10.225 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE220C) (D 0836 LFL 02)	Diesel	6871	162	220	09.00-	■
8.223 LK (D 0826 LFL02)	Diesel	6871	162	220	10.93-06.96	■
8.223 LK (D 0826 LFL06)	Diesel	6871	162	220	10.93-06.96	■
8.224 LK, LRK, L-KI, LR-KI (D 0826 LFL03)	Diesel	6871	162	220	05.94-	■
8.224 LK, LRK, L-KI, LR-KI	Diesel	6871	162	220	05.94-	■
8.225 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE220C) (D 0836 LFL 02)	Diesel	6871	162	220	09.00-	■
9.223 LK (D 0826 LFL02)	Diesel	6871	162	220	10.93-06.96	■
9.223 LK (D 0826 LFL06)	Diesel	6871	162	220	10.93-06.96	■

LISTA DE APLICACIONES - BUYERS GUIDE

9.224 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0826 LFL03)	Diesel		6871	162	220	05.94-	■
9.225 LK, L-KI, LRK, LR-KI, LRK-KI, LK-L (LE220C) (D 0836 LFL 02)	Diesel		6871	162	220	09.00-	■
L2000 06.93-				Municipal Vehicle			
8.145 L-LF	Diesel		4580	103	140	09.00-	■
10.153 F (D 0824 LFL 01)	Diesel		4580	114	155	06.93-04.06	■
10.153 F (D 0824 LFL 05)	Diesel		4580	114	155	06.93-04.06	■
10.163 F (D 0824 LFL 06)	Diesel		4580	114	155	06.93-04.06	■
8.155 L-LF	Diesel		4580	114	155	02.04-	■
8.163 L-LF	Diesel		4580	114	155	05.94-	■
8.163	Diesel		4580	118	160	06.93-08.06	■
8.185 L-LF	Diesel		4580	132	180	09.00-	■
10.223 F, 10.223 FL (D 0826 LFL06)	Diesel		6871	162	220	06.93-04.02	■
10.224 F, 10.224 FL (D 0826 LFL03)	Diesel		6871	162	220	06.93-04.02	■
L2000 06.93-				Platform/Chassis			
6.103	Diesel		4580	75	102	06.93-08.06	■
7.103	Diesel		4580	75	102	06.93-08.06	■
8.103 LC, 8.103 LLC (D 0824 FL 01)	Diesel		4580	75	102	10.93-06.96	■
6.113	Diesel		4580	81	110	06.93-08.06	■
7.113	Diesel		4580	81	110	06.93-08.06	■
7.113	Diesel		4580	81	110	06.00-10.01	■
8.113 LC, 8.113 LLC (D 0824 LFL 04)	Diesel		4580	81	110	08.95-	■
9.113	Diesel		4580	81	110	06.00-10.01	■
6.113	Diesel		4580	83	113	01.97-08.06	■
7.113	Diesel		4580	83	113	01.97-08.06	■
7.113	Diesel		4580	83	113	06.00-10.01	■
8.113 LC,8.113 LLC, LRC, LLRC(LE110C) (D 0824 LFL 08)	Diesel		4580	83	113	09.00-	■
9.113	Diesel		4580	83	113	06.00-10.01	■
10.145 LC,10.145 LLC, LRC, LLRC (LE140C) (D 0834 LFL 02)	Diesel		4580	103	140	09.00-	■
6.143	Diesel		4580	103	140	07.99-08.06	■
6.145	Diesel		4580	103	140	06.00-01.04	■
7.143	Diesel		4580	103	140	07.99-08.06	■
7.145	Diesel		4580	103	140	06.00-01.04	■
8.145 LC, LLC, LLRC, LRC (LE140C) (D 0834 LFL 02)	Diesel		4580	103	140	09.00-	■
9.145 LC,9.145 LLC, LRC, LLRC (LE140C) (D 0834 LFL 02)	Diesel		4580	103	140	09.00-	■
10.145	Diesel		4580	104	141	06.93-04.06	■
6.143	Diesel		4580	104	141	06.93-08.06	■
6.145	Diesel		4580	104	141	06.00-10.01	■
7.143	Diesel		4580	104	141	06.93-08.06	■
7.145	Diesel		4580	104	141	06.00-10.01	■
8.145	Diesel		4580	104	141	06.93-08.06	■
8.145	Diesel		4580	104	141	06.93-06.06	■
9.145	Diesel		4580	104	141	06.93-08.06	■
10.153	Diesel		4580	110	150	07.99-04.06	■
10.155	Diesel		4580	110	150	07.99-04.06	■
6.153	Diesel		4580	110	150	07.99-08.06	■
7.153	Diesel		4580	110	150	07.99-08.06	■
7.153	Diesel		4580	110	150	06.00-01.04	■
8.153	Diesel		4580	110	150	07.99-08.06	■

LISTA DE APLICACIONES - BUYERS GUIDE

8.153		Diesel		4580	110	150	07.99-04.06	■
8.155		Diesel		4580	110	150	07.99-08.06	■
8.155		Diesel		4580	110	150	07.99-04.06	■
9.153		Diesel		4580	110	150	07.99-08.06	■
9.155		Diesel		4580	110	150	07.99-08.06	■
10.153 LC,10.153 LLC (D 0824 LFL 01)		Diesel		4580	114	155	10.93-06.96	■
10.153 LC,10.153 LLC (D 0824 LFL 05)		Diesel		4580	114	155	10.93-06.96	■
10.155 LC, LLC, LLRC, LRC, LLRC		Diesel		4580	114	155	09.00-	■
10.163 LC,10.163 LLC (D 0824 LFL 02)		Diesel		4580	114	155	05.94-	■
10.163 LC,10.163 LLC (D 0824 LFL 06)		Diesel		4580	114	155	05.94-	■
10.163 LC,10.163 LLC (D 0824 LFL 09)		Diesel		4580	114	155	05.94-	■
10.163 LC,10.163 LLC, LRC, LLRC (LE160C) (D 0824 LFL 09)		Diesel		4580	114	155	09.00-	■
6.153		Diesel		4580	114	155	06.93-08.06	■
6.163		Diesel		4580	114	155	04.97-08.06	■
7.153		Diesel		4580	114	155	06.93-08.06	■
7.153		Diesel		4580	114	155	06.00-10.01	■
7.163		Diesel		4580	114	155	04.97-08.06	■
8.153 LC,8.153 LLC (D 0824 LFL 01)		Diesel		4580	114	155	10.93-07.97	■
8.153 LC,8.153 LLC (D 0824 LFL 05)		Diesel		4580	114	155	10.93-07.97	■
8.155 L, LR, LC, LLC, LRC, LLRC, L-LF		Diesel		4580	114	155	02.04-	■
8.155 LC, LLC, LRC, LLRC		Diesel		4580	114	155	02.04-	■
8.163 LC,8.163 LLC (D 0824 LFL 02)		Diesel		4580	114	155	05.94-	■
8.163 LC,8.163 LLC (D 0824 LFL 06)		Diesel		4580	114	155	05.94-	■
8.163 LC,8.163 LLC (D 0824 LFL 09)		Diesel		4580	114	155	05.94-	■
8.163 LC, LLC, LLRC, LRC (LE160C) (D 0824 LFL 09)		Diesel		4580	114	155	09.00-	■
9.153 LC,9.153 LLC (D 0824 LFL 01)		Diesel		4580	114	155	10.93-06.96	■
9.153 LC,9.153 LLC (D 0824 LFL 05)		Diesel		4580	114	155	10.93-06.96	■
9.155 L, LC, LLC, LRC, LLRC		Diesel		4580	114	155	02.04-	■
9.163 LC,9.163 LLC, LRC, LLRC (D 0824 LFL 02)		Diesel		4580	114	155	05.94-	■
9.163 LC,9.163 LLC, LRC, LLRC (D 0824 LFL 06)		Diesel		4580	114	155	05.94-	■
9.163 LC,9.163 LLC, LRC, LLRC (D 0824 LFL 09)		Diesel		4580	114	155	05.94-	■
6.163		Diesel		4580	118	160	06.93-08.06	■
7.163		Diesel		4580	118	160	06.93-08.06	■
7.163		Diesel		4580	118	160	06.00-10.01	■
10.174		Diesel		4580	125	170	06.00-01.04	■
6.174		Diesel		4580	125	170	07.99-08.06	■
7.174		Diesel		4580	125	170	07.99-08.06	■
7.174		Diesel		4580	125	170	06.00-01.04	■
8.174		Diesel		4580	125	170	06.00-01.04	■
9.174		Diesel		4580	125	170	06.00-01.04	■
10.185 LC,10.185 LLC, LRC, LLRC (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■
6.185		Diesel		4580	132	179	06.00-01.04	■
7.185		Diesel		4580	132	179	06.00-01.04	■
8.185 LC, LLC, LRC, LLRC (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■
9.185 LC,9.185 LLC, LRC, LLRC (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■
10.223 LC,10.223 LLC (D 0826 LFL02)		Diesel		6871	162	220	10.93-06.96	■
10.223 LC,10.223 LLC (D 0826 LFL06)		Diesel		6871	162	220	10.93-06.96	■

LISTA DE APLICACIONES - BUYERS GUIDE

10.224 LC,10.224 LLC, LRC, LLRC (D 0826 LFL03)	Diesel		6871	162	220	05.94-	■
10.224 LC,10.224 LLC, LRC, LLRC (D 0826 LFL10)	Diesel		6871	162	220	05.94-	■
10.225 LC, 10.225 LLC, LRC, LLRC (LE220C) (D 0836 LFL 02)	Diesel		6871	162	220	09.00-	■
10.225 LC, 10.225 LLC, LRC, LLRC (LE220C) (D 0836 LFL 02)	Diesel		6871	162	220	09.00-	■
8.223 LC,8.223 LLC (D 0826 LFL02)	Diesel		6871	162	220	10.93-06.96	■
8.223 LC,8.223 LLC (D 0826 LFL06)	Diesel		6871	162	220	10.93-06.96	■
8.224 LC,8.224 LLC, LRC, LLRC (D 0826 LFL03)	Diesel		6871	162	220	05.94-	■
8.224 LC, LLC, LRC, LLRC	Diesel		6871	162	220	05.94-	■
8.225 LC,8.225 LLC, LRC, LLRC (LE220C) (D 0826 LFL10)	Diesel		6871	162	220	09.00-	■
8.225 LC,8.225 LLC, LRC, LLRC (LE220C) (D 0836 LFL 02)	Diesel		6871	162	220	09.00-	■
9.223 LC,9.223 LLC (D 0826 LFL02)	Diesel		6871	162	220	10.93-06.96	■
9.223 LC,9.223 LLC (D 0826 LFL06)	Diesel		6871	162	220	10.93-06.96	■
9.224 LC,9.224 LLC, LRC, LLRC (D 0826 LFL03)	Diesel		6871	162	220	05.94-	■
9.225 LC,9.225 LLC, LRC, LLRC (LE220C) (D 0836 LFL 02)	Diesel		6871	162	220	09.00-	■
L2000 06.93-				Truck Tractor			
6.103	Diesel		4580	75	102	06.93-08.06	■
7.103	Diesel		4580	75	102	06.93-08.06	■
8.103	Diesel		4580	75	102	06.93-08.06	■
6.113	Diesel		4580	81	110	06.93-08.06	■
7.113	Diesel		4580	81	110	06.93-08.06	■
8.113	Diesel		4580	81	110	06.93-08.06	■
6.113	Diesel		4580	83	113	01.97-08.06	■
7.113	Diesel		4580	83	113	01.97-08.06	■
8.113	Diesel		4580	83	113	01.97-08.06	■
10.145 LLS, LLRS (LE140C) (D 0834 LFL 02)	Diesel		4580	103	140	09.00-	■
6.143	Diesel		4580	103	140	07.99-08.06	■
7.143	Diesel		4580	103	140	07.99-08.06	■
8.145 LLS, LLRS (LE140C) (D 0834 LFL 02)	Diesel		4580	103	140	09.00-	■
9.145 LLS, LLRS (LE140C) (D 0834 LFL 02)	Diesel		4580	103	140	09.00-	■
10.145	Diesel		4580	104	141	06.93-03.06	■
6.143	Diesel		4580	104	141	06.93-08.06	■
7.143	Diesel		4580	104	141	06.93-08.06	■
8.145	Diesel		4580	104	141	06.93-08.06	■
9.145	Diesel		4580	104	141	06.93-08.06	■
6.153	Diesel		4580	110	150	07.99-08.06	■
7.153	Diesel		4580	110	150	07.99-08.06	■
8.153	Diesel		4580	110	150	07.99-08.06	■
8.155	Diesel		4580	110	150	07.99-08.06	■
9.153	Diesel		4580	110	150	07.99-08.06	■
9.155	Diesel		4580	110	150	07.99-08.06	■
10.163 LLS, LLRS (D 0824 LFL 02)	Diesel		4580	114	155	05.94-	■
10.163 LLS, LLRS (D 0824 LFL 06)	Diesel		4580	114	155	05.94-	■
10.163 LLS, LLRS (D 0824 LFL 09)	Diesel		4580	114	155	05.94-	■
6.153	Diesel		4580	114	155	06.93-08.06	■
6.163	Diesel		4580	114	155	04.97-08.06	■
7.153	Diesel		4580	114	155	06.93-08.06	■
7.163	Diesel		4580	114	155	04.97-08.06	■

LISTA DE APLICACIONES - BUYERS GUIDE

8.153 LLS (D 0824 LFL 01)	Diesel		4580	114	155	10.93-06.96	■
8.153 LLS (D 0824 LFL 05)	Diesel		4580	114	155	10.93-06.96	■
8.155 LLS, LLRS	Diesel		4580	114	155	02.04-	■
8.155 LLS, LLRS	Diesel		4580	114	155	02.04-	■
8.163 LLS, LLRS (D 0824 LFL 02)	Diesel		4580	114	155	05.94-	■
8.163 LLS, LLRS (D 0824 LFL 06)	Diesel		4580	114	155	05.94-	■
8.163 LLS, LLRS (D 0824 LFL 09)	Diesel		4580	114	155	05.94-	■
8.163 LLS, LLRS	Diesel		4580	114	155	05.94-	■
9.155 LLS, LLRS	Diesel		4580	114	155	02.04-	■
9.163 LLS, LLRS (D 0824 LFL 02)	Diesel		4580	114	155	05.94-	■
9.163 LLS, LLRS (D 0824 LFL 06)	Diesel		4580	114	155	05.94-	■
9.163 LLS, LLRS (D 0824 LFL 09)	Diesel		4580	114	155	05.94-	■
6.163	Diesel		4580	118	160	06.93-08.06	■
7.163	Diesel		4580	118	160	06.93-08.06	■
6.174	Diesel		4580	125	170	07.99-08.06	■
7.174	Diesel		4580	125	170	07.99-08.06	■
10.185 LLS, LLRS (LE180C) (D 0834 LFL 03)	Diesel		4580	132	180	09.00-	■
8.185 LLS, LLRS (LE180C) (D 0834 LFL 03)	Diesel		4580	132	180	09.00-	■
9.185 LLS, LLRS (LE 180C) (D 0834 LFL 03)	Diesel		4580	132	180	09.00-	■
10.223 LLS (D 0826 LFL02)	Diesel		6871	162	220	10.93-06.96	■
10.223 LLS (D 0826 LFL06)	Diesel		6871	162	220	10.93-06.96	■
10.224 LLS, LLRS (D 0826 LFL03)	Diesel		6871	162	220	05.94-	■
10.225 LLS, LLRS (LE220C) (D 0836 LFL 02)	Diesel		6871	162	220	09.00-	■
8.223 LLS (D 0826 LFL02)	Diesel		6871	162	220	10.93-06.96	■
8.223 LLS (D 0826 LFL06)	Diesel		6871	162	220	10.93-06.96	■
8.224 LLS, LLRS (D 0826 LFL03)	Diesel		6871	162	220	05.94-	■
8.224 LLS, LLRS	Diesel		6871	162	220	05.94-	■
8.225 LLS, LLRS (LE220C) (D 0836 LFL 02)	Diesel		6871	162	220	09.00-	■
9.223 LLS (D 0826 LFL02)	Diesel		6871	162	220	10.93-06.96	■
9.223 LLS (D 0826 LFL06)	Diesel		6871	162	220	10.93-06.96	■
9.224 LLS, LLRS (D 0826 LFL03)	Diesel		6871	162	220	05.94-	■
9.225 LLS, LLRS (LE220C) (D 0836 LFL 02)	Diesel		6871	162	220	09.00-	■
M 2000 L 04.95-				Platform/Chassis			
12.163	Diesel		4580	118	160	04.95-08.06	■