

LISTA DE APLICACIONES - BUYERS GUIDE

79KT0078 C



8 424073 107299

Weight: 2.563

O.E.M.	MAKE
4241.H4	PEUGEOT
4251 H4	CITROËN
4251.H4	PEUGEOT
9 942 885	FIAT
9 945 885	FIAT



79KT0078 C

E1 90R-01489/025



Lucas - Girling

Ø254 x 57 - Ø25.4

MAKE
CITROËN
FIAT
PEUGEOT



Trac.	CC	Kw	CV	
				Front / Rear

CITROËN

JUMPER II / RELAY (230P) 02.94-04.02

						Bus (Minibus-M2-Segment)			
2.0 (RFW (XU10J2U))		Gasolina	FWD	1998	80	109	02.94-04.02		■
2.0 4x4 (RFW (XU10J2U))		Gasolina	4WD	1998	80	109	08.96-04.02		■
1.9 D (D9B (XUD9A/U))		Diesel	FWD	1905	51	69	01.99-04.02		■
1.9 TD (D8C (XUD9UTF))	-10/98	Diesel	FWD	1905	66	90	08.94-04.02		■
1.9 TD (D8C (XUD9UTF))	-10/98	Diesel	FWD	1905	68	92	02.94-04.02		■
1.9 TD 4x4 (D8C (XUD9UTF))		Diesel	4WD	1905	68	92	08.96-04.02		■
2.5 D (T9A (DJ5))		Diesel	FWD	2446	63	86	08.94-04.02		■
2.5 D 4x4 (T9A (DJ5))		Diesel	4WD	2446	63	86	08.96-04.02		■
2.5 TD (T8A (DJ5T))	-09/00	Diesel	FWD	2446	76	103	08.94-04.02		■
2.5 TD 4x4 (T8A (DJ5T))		Diesel	4WD	2446	76	103	08.96-04.02		■
2.5 TDI (THX (DJ5TED))		Diesel	FWD	2446	79	107	12.96-11.00		■
2.5 TDI 4x4 (THX (DJ5TED))		Diesel	4WD	2446	79	107	12.96-11.00		■
2.8 D (8140.63 (F28D))		Diesel	FWD	2798	64	87	01.99-02.02		■
2.8 HDI (8140.43S)		Diesel	FWD	2798	94	128	09.00-04.02		■
2.8 HDi 4x4 (8140.43S)		Diesel	4WD	2798	94	128	09.00-04.02		■

JUMPER II / RELAY (230) 03.94-04.02

						Platform/Chassis (LCVs-N1 Segment)			
2.0 (RFW (XU10J2U))		Gasolina	FWD	1998	80	109	03.94-04.02		■
1.9 TD (DHX (XUD9TF/BTF))		Diesel	FWD	1905	66	90	03.94-04.02		■
1.9 TD (D8C (XUD9UTF))		Diesel	FWD	1905	68	92	03.94-04.02		■
2.5 D (T9A (DJ5))		Diesel	FWD	2446	63	86	03.94-04.02		■
2.5 D 4x4 (T9A (DJ5))		Diesel	4WD	2446	63	86	03.00-04.02		■
2.5 TD (T8A (DJ5T))		Diesel	FWD	2446	76	103	03.94-04.02		■

LISTA DE APLICACIONES - BUYERS GUIDE

2.5 TDI (THX (DJ5TED))	-09/00	Diesel	FWD	2446	79	107	12.96-04.02	■
2.5 TDI 4x4 (THX (DJ5TED))		Diesel	4WD	2446	79	107	03.00-04.02	■
2.8 HDI		Diesel	FWD	2798	93	126	10.00-01.02	■
2.8 HDI (8140.43S)		Diesel	FWD	2798	94	128	09.00-04.02	■
JUMPER II / RELAY (230L) 02.94-08.02					Van (LCVs-N1 Segment)			
2.0 (RFW (XU10J2U))		Gasolina	FWD	1998	80	109	03.94-04.02	■
2.0 4x4 (RFW (XU10J2U))	09/97-, -10/00	Gasolina	4WD	1998	80	109	10.96-01.02	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	07.99-04.02	■
1.9 D (D9B (XUD9A/U))		Diesel	FWD	1905	51	69	02.94-04.02	■
1.9 TD (DHX (XUD9TF/BTF))		Diesel	FWD	1905	66	90	03.94-04.02	■
1.9 TD (D8C (XUD9UTF))	-10/98	Diesel	FWD	1905	68	92	03.94-04.02	■
2.5 D (T9A (DJ5))		Diesel	FWD	2446	63	86	03.94-04.02	■
2.5 D 4x4 (T9A (DJ5))		Diesel	4WD	2446	63	86	03.00-04.02	■
2.5 DT 4x4 (THZ (DJ5T))		Diesel	4WD	2446	76	103	10.96-08.97	■
2.5 TD (T8A (DJ5T))		Diesel	FWD	2446	76	103	03.94-04.02	■
2.5 TDI (THX (DJ5TED))		Diesel	FWD	2446	79	107	12.96-11.00	■
2.5 TDI 4x4 (THX (DJ5TED))		Diesel	4WD	2446	79	107	03.00-11.00	■
2.8 D (8140.63 (F28D))		Diesel	FWD	2798	64	87	01.99-02.02	■
2.8 HDI (8140.43S)		Diesel	FWD	2798	94	128	09.00-04.02	■
2.8 HDi 4x4 (8140.43S)		Diesel	4WD	2798	94	128	09.00-04.02	■
FIAT								
DUCATO (280_) 07.82-08.90					Bus (Minibus-M2-Segment)			
2.4 D (8144.61)		Diesel	FWD	2445	53	72	07.82-12.85	■
DUCATO (280_) 01.82-02.91					Van (LCVs-N1 Segment)			
2.4 D (8144.61)	-05/86	Diesel	FWD	2445	53	72	01.82-08.90	■
DUCATO II (230_) 03.94-05.05					Bus (Minibus-M2-Segment)			
2.0		Gasolina	FWD	1998	74	101	06.94-12.95	■
2.0 4x4 (RFW)		Gasolina	4WD	1998	80	109	11.94-11.01	■
2.0 Panorama/Combinato (RFW)	-08/01	Gasolina	FWD	1998	80	109	03.94-04.02	■
1.9 D (DJY)	-10/00	Diesel	FWD	1905	50	68	04.98-04.02	■
1.9 D (DHX)		Diesel	FWD	1905	59	80	05.98-11.01	■
1.9 TD (DHX)	-11/01	Diesel	FWD	1905	66	90	04.98-04.02	■
1.9 TD (DHX (XUD9TF/L))	-11/01	Diesel	FWD	1905	66	90	04.98-04.02	■
1.9 D Combinato (230 A2.000)	-08/98	Diesel	FWD	1929	51	69	06.95-04.02	■
1.9 TD Combinato (230 A4.000)	-04/98	Diesel	FWD	1929	59	80	08.94-04.02	■
1.9 TD Panorama/Combinato (230 A3.000)	-08/98	Diesel	FWD	1929	60	82	03.94-04.02	■
2.5 D		Diesel	FWD	2499	55	75	03.94-04.02	■
2.8 D (8140.63)	09/99-, -08/01	Diesel	FWD	2800	64	87	02.98-04.02	■
2.8 TDI (8140.43)	05/98-, -08/01	Diesel	FWD	2800	90	122	10.97-04.02	■
2.8 TDI 4x4 (8140.43)		Diesel	4WD	2800	90	122	07.99-04.02	■
DUCATO II (230_) 03.94-04.02					Platform/Chassis (LCVs-N1 Segment)			
2.0 (RFW)	-08/01	Gasolina	FWD	1998	80	109	03.94-04.02	■
1.9 D (DJY)		Diesel	FWD	1905	50	68	04.98-04.02	■
1.9 TD (DHX)		Diesel	FWD	1905	59	80	05.98-11.01	■
1.9 TD (DHX)		Diesel	FWD	1905	66	90	04.98-04.02	■
1.9 TD (DHX (XUD9TF/L))		Diesel	FWD	1905	66	90	04.98-04.02	■
1.9 D (230 A2.000)	11/94-, -08/98	Diesel	FWD	1929	51	69	03.94-04.02	■
1.9 TD CAT (230 A4.000)	-08/98	Diesel	FWD	1929	59	80	08.94-04.02	■
1.9 TD (230 A3.000)	-04/98	Diesel	FWD	1929	60	82	03.94-04.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

2.5 TDI 4x4 (8140.47)	09/99-	Diesel	4WD	2500	85	116	06.98-04.02	■
2.8 TD 4x4 (8140.63)	09/99-	Diesel	4WD	2799	64	87	05.98-11.01	■
2.8 iDTD 4x4 (8140.43)	09/99-	Diesel	4WD	2799	90	122	05.98-09.01	■
2.8 D (8140.63)	09/99-	Diesel	FWD	2800	64	87	02.98-04.02	■
DUCATO II (230_) 03.94-05.05					Van (LCVs-N1 Segment)			
2.0		Gasolina	FWD	1998	74	101	06.94-12.95	■
2.0 (RFW)		Gasolina	FWD	1998	80	109	03.94-04.02	■
2.0 4x4 (RFW)		Gasolina	4WD	1998	80	109	11.94-04.02	■
1.9 D (DJY)	-10/00	Diesel	FWD	1905	50	68	04.98-04.02	■
1.9 TD (DHX)		Diesel	FWD	1905	59	80	05.98-11.01	■
1.9 TD (DHX)	-11/01	Diesel	FWD	1905	66	90	04.98-04.02	■
1.9 TD (DHX (XUD9TF/L))	-11/01	Diesel	FWD	1905	66	90	04.98-04.02	■
1.9 D (230 A2.000)	11/94-, -08/98	Diesel	FWD	1929	51	69	03.94-04.02	■
1.9 TD CAT (230 A4.000)	-08/98	Diesel	FWD	1929	59	80	08.94-04.02	■
1.9 TD (230 A3.000)	-04/98	Diesel	FWD	1929	60	82	03.94-04.02	■
2.5 TD 4x4 (8140.47)		Diesel	4WD	2499	80	109	11.94-04.98	■
2.8 TD 4x4 (8140.43)	09/99-	Diesel	4WD	2799	90	122	05.98-09.01	■
2.8 D (8140.63)	09/99-	Diesel	FWD	2800	64	87	05.98-04.02	■
2.8 D 4x4 (8140.63)	09/99-	Diesel	4WD	2800	64	87	08.98-04.02	■
2.8 TDI (8140.43)	09/99-	Diesel	FWD	2800	90	122	10.97-04.02	■
2.8 TDI 4x4 (8140.43)	-08/01	Diesel	4WD	2800	90	122	06.99-04.02	■
PEUGEOT								
BOXER II (230P) 03.94-12.09					Bus (Minibus-M2-Segment)			
2.0 i (RFW (XU10J2))	-11/01	Gasolina	FWD	1998	80	109	03.94-04.02	■
2.0 i 4x4 (RFW (XU10J2))	-11/01	Gasolina	4WD	1998	80	109	08.96-04.02	■
1.9 D (D9B (XUD9AU))		Diesel	FWD	1905	51	69	03.94-04.02	■
1.9 TD (DHY (XUD9TE))	-11/01	Diesel	FWD	1905	66	90	08.94-04.02	■
1.9 TD (D8C (XUD9UTF))	-11/01	Diesel	FWD	1905	68	92	03.94-04.02	■
1.9 TD 4x4 (D8C (XUD9UTF))		Diesel	4WD	1905	68	92	07.96-04.02	■
2.5 D (T9A (DJ5))		Diesel	FWD	2446	63	86	08.94-04.02	■
2.5 D 4x4 (T9A (DJ5))		Diesel	4WD	2446	63	86	07.96-04.02	■
2.5 TD (T8A (DJ5T))		Diesel	FWD	2446	76	103	07.94-12.97	■
2.5 TD 4x4 (T8A (DJ5T))		Diesel	4WD	2446	76	103	07.96-04.02	■
2.5 TDI (THX (DJ5TED))		Diesel	FWD	2446	79	107	01.97-04.02	■
2.5 TDI 4x4 (THX (DJ5TED))		Diesel	4WD	2446	79	107	01.97-04.02	■
2.5 DT		Diesel	FWD	2499	62	84	10.97-11.01	■
2.8 DTIC		Diesel	FWD	2798	90	122	10.97-09.00	■
2.8 HDI (8140.43S (F28DTCR))		Diesel	FWD	2798	93	126	10.00-11.01	■
2.8 HDI (8140.43S (F28DTCR))		Diesel	FWD	2798	94	128	11.00-04.02	■
2.8 HDi 4x4 (8140.43S (F28DTCR))		Diesel	4WD	2798	94	128	10.00-04.02	■
BOXER II (ZCT_) 03.94-04.02					Platform/Chassis (LCVs-N1 Segment)			
2.0 i (RFW (XU10J2))	-11/01	Gasolina	FWD	1998	80	109	06.94-04.02	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	51	69	03.94-04.02	■
1.9 TD (DHY (XUD9TE))		Diesel	FWD	1905	66	90	06.94-04.02	■
1.9 TD (XUD9TE)		Diesel	FWD	1905	66	90	06.94-04.02	■
1.9 TD (D8C (XUD9UTF))		Diesel	FWD	1905	68	92	07.94-04.02	■
1.9 TD (XUD9TE)		Diesel	FWD	1905	68	92	07.94-04.02	■
2.5 D (T9A (DJ5))		Diesel	FWD	2446	63	86	03.94-04.02	■
2.5 D 4x4 (T9A (DJ5))		Diesel	4WD	2446	63	86	07.99-04.02	■
2.5 TD (T8A (DJ5T))		Diesel	FWD	2446	76	103	03.94-12.97	■

LISTA DE APLICACIONES - BUYERS GUIDE

2.5 TDI (THX (DJ5TED))		Diesel	FWD	2446	79	107	01.97-04.02	■
2.5 TDI 4x4 (THX (DJ5TED))		Diesel	4WD	2446	79	107	07.99-04.02	■
2.8 HDI (8140.43S (F28DTCR))		Diesel	FWD	2798	93	126	10.00-11.01	■
2.8 HDI (8140.43S (F28DTCR))		Diesel	FWD	2798	94	128	11.00-04.02	■
BOXER II (230L) 03.94-08.06					Van (LCVs-N1 Segment)			
2.0 4x4 (RFW (XU10J2))		Gasolina	4WD	1998	80	109	03.96-09.98	■
2.0 i (RFW (XU10J2))		Gasolina	FWD	1998	80	109	06.94-04.02	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	07.99-04.02	■
1.9 D (D9B (XUD9AU))	-11/01	Diesel	FWD	1905	51	69	03.94-04.02	■
1.9 DT 4x4 (XUD9TE)		Diesel	4WD	1905	66	90	03.96-09.98	■
1.9 TD (XUD9TE)		Diesel	FWD	1905	66	90	07.99-04.02	■
1.9 TD (D8C (XUD9UTF))	-11/01	Diesel	FWD	1905	68	92	03.94-04.02	■
2.0 HDi (RHV (DW10UTD))		Diesel	FWD	1997	62	84	08.01-04.02	■
2.5 D (T9A (DJ5))		Diesel	FWD	2446	63	86	03.94-04.02	■
2.5 D 4x4 (T9A (DJ5))		Diesel	4WD	2446	63	86	07.99-04.02	■
2.5 TD (T8A (DJ5T))		Diesel	FWD	2446	76	103	03.94-03.02	■
2.5 TDI (THX (DJ5TED))		Diesel	FWD	2446	79	107	01.97-04.02	■
2.5 TDI 4x4 (THX (DJ5TED))		Diesel	4WD	2446	79	107	07.99-04.02	■
2.5 DT		Diesel	FWD	2499	62	84	10.97-11.01	■
2.8 DTiC		Diesel	FWD	2798	90	122	10.97-08.05	■
2.8 HDI (8140.43S (F28DTCR))		Diesel	FWD	2798	93	126	10.00-11.01	■
2.8 HDi 4x4 (8140.43S (F28DTCR))		Diesel	4WD	2798	93	126	10.00-11.01	■
2.8 HDI (8140.43S (F28DTCR))		Diesel	FWD	2798	94	128	11.00-04.02	■
2.8 HDi 4x4 (8140.43S (F28DTCR))		Diesel	4WD	2798	94	128	10.00-04.02	■